




Fi-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003735	MAIN BODY	702	27020478	PINION GEAR
105	21050012	PINION BEARING FIXED PLATE	705	27050099	TRANSMISSION GEAR
105-1	21050038	PINION BEARING FIXED PLATE	708	27080096	OSCILLATING SLIDER
108	21087072	CAP	716	27160008	OSCILLATION SLIDER PLATE
200	22003855	SIDE PLATE	718	27180703	MAIN SHAFT
201	22010481	MIAN BODY DECORATION	719	27190025	CLICK GEAR
201-1	22010482	SIDE PLATE DECORATION	722	27220009	CLICK GEAR WASHER
201-2	22010562	SIDE PLATE DECORATION	725	27250023	TRANSMISSION GEAR
201-3	22010561	SIDE PLATE DECORATION	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
300	23004671	ROTOR	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
301	23011625	BAIL ARM	801	28010024	ANTI-RE LEVER SPRING
304	23042670	BAIL ARM COVER	0910496	0910496	BALL BEARING
305	23050141	KICK LEVER	0910039	0910039	BALL BEARING
306	23061035	BAIL HOLDER COVER	0910374	0910374	BALL BEARING
307	23071427	BAIL HOLDER	0910091	0910091	BALL BEARING
309	23090002	BAIL ARM SLIDER	0910013	0910013	BALL BEARING
310	23100002	COMPRESSION SPRING	0910015	0910015	BALL BEARING
313	23131451	BAIL WIRE ASSY.	0920319	0920319	WASHER
315	23150022	LINE ROLLER	0920376	0920376	WASHER
317	23170008	LINE ROLLER WASHER	0920154	0920154	WASHER
318	23180005	ROTOR NUT	0930438	0930438	SCREW
400	240014704	SPOOL ASSY.	0930541	0930541	SCREW
405	24050042	DRAG WASHER RETAINER	0930471	0930471	SCREW
407	24070006	EXTENSION SPRING	0930209	0930209	SCREW
500	25005854	HANDLE ASSY.	0930058	0930058	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930597	0930597	SCREW
513	25130780	HANDLE CAP	0930544	0930544	SCREW
600	26002995	DRAG KNOB ASSY.	09301265	09301265	SCREW
610	26100011	DRAG WASHER	0930307	0930307	SCREW
611	26110005	EARED WASHER	0930429	0930429	SCREW
612	26120007	KEY WASHER	0930838	0930838	SCREW
612-3	26120032	KEY WASHER	0930663	0930663	SCREW
700	27000318	DRIVE GEAR			

s



ReelSchematic