




HSX-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004505	Main body	700	27002022	Drive gear
105	21050012	Pinion bearing fixed plate	702	27020946	Pinion gear
105-1	21056571	Pinion bearing fixed plate	705	27050209	Transmission gear
105-2	21050071	Pinion bearing fixed bushing	708	27080182	Oscillatory slider
112	21120189	Foot label decoration	716	27160008	Oscillation slider plate
200	22004601	Side plate	718	27180791	Main shaft
201	22010965	Main body decoration	719	27190025	Click gear
201-1	22010966	Side plate decoration	722	27220009	Click gear washer
300	23005176	Rotor	800	28000437	Anti-reverse/anti-re lever
301	23012268	Bail arm	800-1	28000324	Anti-reverse/anti-re lever
304	23042843	Bail arm cover	801	28010024	Anti-re lever spring
305	23050224	Kick lever	0910525	0910525	Ball bearing
307	23071864	Bail holder	0910256	0910256	Ball bearing
309	23090051	Bail arm support pin	0910054	0910054	Ball bearing
310	23100090	Compression spring	0910278	0910278	Ball bearing
313	23131799	Bail wire assy.	0910221	0910221	Ball bearing
315	23150086	Line roller	0920376	0920376	Washer
316	23160014	Line roller bushing	0920590	0920590	Washer
317	23170014	Line roller washer	0920154	0920154	Washer
318	23180005	Rotor nut	0920237	0920237	Washer
320	23201166	Rotor balance weight	0930438	0930438	Screw
400	240015805	Spool assy.	0930541	0930541	Screw
405	24050042	Drag washer retainer	09301420	09301420	Screw
407	24070009	Extension spring	0930209	0930209	Screw
412	24120038	Spool bushing	09301533	09301533	Screw
500	25006370	Handle assy.	0930044	0930044	Screw
504	25040007	Handle screw cap washer	0930471	0930471	Screw
513	25130830	Handle cap	09301072	09301072	Screw
600	26004347	Drag knob assy.	09301468	09301468	Screw
610	26100133	Drag washer	0930794	0930794	Screw
611	26110005	Eared washer	0930429	0930429	Screw
612	26120007	Key washer	0930643	0930643	Screw
612-1	26120054	Key washer	09301471	09301471	Screw

209OKA10205301