




Hx-35 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003989	Main body	612	26120007	Key washer
105	21050027	Pinion bearing fixed plate	700	27002017	Drive gear
105	21056578	Pin. bearing fixed plate	702	27020755	Pinion gear
108	21081451	Cap	705	27050150	Transmission gear
200	22004319	Side plate	708	27080168	Oscillating slider
201	22010419	Main body decoration	716	27160007	Oscillation slider plate
201	22010420	Side plate decoration	718	27180735	Main shaft
201	22010445	Main body decoration	719	27190025	Click gear
201	22010446	Side plate decoration	722	27220009	Click gear washer
300	23004851	Rotor	725	27250020	Transmission gear bushing
301	23011926	Bail arm	800	28000241	Anti-reverse/anti-re lever
304	23042610	Bail arm cover	800	28000322	Anti-reverse/anti-re lever
305	23050146	Kick lever	801	28010024	Anti-re lever spring
307	23071531	Bail holder	0910054	0910054	Ball bearing
309	23090002	Bail arm slider	0910221	0910221	Ball bearing
310	23100005	Compression spring	0910256	0910256	Ball bearing
313	23131574	Bail wire assy.	0910278	0910278	Ball bearing
315	23150086	Line roller	0910526	0910526	Ball bearing
316	23160014	Line roller bushing	0920154	0920154	Washer
317	23170024	Line roller washer	0920376	0920376	Washer
318	23180005	Rotor nut	0920540	0920540	Washer
400	240013792	Spool assy.	0920237	0920237	Washer
405	24050042	Darg washer retainer	0920590	0920590	Washer
407	24070009	Extension spring	09301377	09301377	Screw
412	24120038	Spool bushing	09301379	09301379	Screw
413	24130009	Waterproof retainer	09301380	09301380	Screw
500	25005656	Handle assy.	0930171	0930171	Screw
504	25040004	Handle screw cap washer	0930209	0930209	Screw
513	25130826	Handle cap assy.	0930438	0930438	Screw
600	26003787	Drag knob assy.	0930471	0930471	Screw
610	26100109	Drag washer	0930575	0930575	Screw
611	26110005	Eared washer	0930639	0930639	Screw
612	26120006	Key washer	0930643	0930643	Screw
612	26120054	Key washer	09301374	09301374	Screw

209OKA09303351