





Hx-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO
100	21003989	MIAN BODY	612-1	26120054
105	21050027	PINION BEARING FIXED PLATE	612-2	26120007
105-1	21050036	PIN. BEARING FIXED PLATE	700	27002017
108	21081451	CAP	702	27020755
200	22004319	SIDE PLATE	705	27050150
201	22010419	MAIN BODY DECORATION	708	27080127
201-1	22010420	SIDE PLATE DECORATION	716	27160007
201-2	22010445	MAIN BODY DECORATION	718	27180735
201-3	22010446	SIDE PLATE DECORATION	719	27190025
300	23004851	ROTOR	722	27220009
301	23011926	BAIL ARM	725	27250020
304	23042610	BAIL ARM COVER	800	28000241
305	23050146	KICK LEVER	800-1	28000322
307	23071531	BAIL HOLDER	801	28010024
309	23090002	BAIL ARM SLIDER	0910054	0910054
310	23100005	COMPRESSION SPRING	0910221	0910221
313	23131574	BAIL WIRE ASSY.	0910256	0910256
315	23150029	LINE ROLLER	0910278	0910278
317	23170024	LINE ROLLERWASHER	0910495	0910495
317-1	23170013	LINE ROLLERWASHER	0920154	0920154
318	23180005	ROTOR NUT	0920376	0920376
400	240013793	SPOOL ASSY.	0920540	0920540
405	24050042	DARG WASHER RETAINER	09301377	09301377
407	24070010	EXTENSION SPRING	09301379	09301379
412	24120038	SPOOL BUSHING	09301380	09301380
413	24130009	WATERPROOF RETAINER	0930171	0930171
500	25005656	HANDLE ASSY.	0930209	0930209
504	25040004	HANDLE SCREW CAP WASHER	0930438	0930438
513	25130826	HANDLE CAP ASSY.	0930471	0930471
600	26003005	DRAG KNOB ASSY.	0930575	0930575
610	26100109	DRAG WASHER	0930639	0930639
611	26110005	EARED WASHER	0930643	0930643
612	26120006	KEY WASHER	09301374	09301374



PARTS NAME
KEY WASHER
KEY WASHER
DRIVE GEAR
PINION GEAR
TRANSMISSION GEAR
OSCILLATING SLIDER
OSCILLATION SLIDER PLATE
MAIN SHAFT
CLICK GEAR
CLICK GEAR WASHER
TRANSMISSION GEAR BUSHING
ANTI-REVERSE/ANTI-RE LEVER
ANTI-REVERSE/ANTI-RE LEVER
ANTI-RE LEVER SPRING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
WASHER
WASHER
WASHER
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW

209OKA09303401