



ID - 150LX Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	4100249	1410001404004	BODY ASSY.		705	47050003	14705001-06	TRANSMISSION GEAR	
105	41050001	14105001-01001	WORM SHAFT BUSHING		706	47060002	14706001-0114	TRANSMISSION GEAR	3107
117	41170001	14117001-03	NUT		707	47070002	14707001-0114	TRANSMISSION GEAR	
200	42000074	1420000204912	HANDLE SIDE PLATE		707	47070003		TRANSMISSION GEAR	
202	42020001	14202001-06	RATCH	3045	709	47090002	14709001-03	TRANSMISSION GEAR BUSHING	
202	42020006	1420200401	RATCH		711	47110012	1471100111003	GUIDE SLIDE BASE ASSY	
206	42060003	14206002-01002	CONTROL PIN CAP		712	47120001	14712001-03001	WORM SHAFT	
226	42260001	14226001-03001	CONTROL PIN		713	47130003	14713001-0170	LINE GUIDE PAWL CAP	
220	42200001	14220001-03907	SIDE PLATE HOLDDED SCREW		715	17150008	11715003-06001C	LINE GUIDE PAWL	
221	42210001	14221001-07	O RING		720	47200002	14720001-06001	DRIVE GEAR SHAFT BUSHING	
222	42220003	14222002-01	MAIN SIDE PLATE HOLDER	3104	800	48000002	14800001-06	CLUTCH SHAFT	
222	42220005	14222001-01001	MAIN SIDE PLATE HOLDER		801	48010003	14801002-06001	CLUTCH SHAFT SPRING	
226	42260001	14226001-03001	CONTROL PIN		802	48020004	14802001-0170	CLUTCH BAR	
300	43000007	14300001-04912	SIDE PLATE		803	48030002	14803001-06	CLUTCH BAR SUPPORT	
302	43020002	14302001-03	WASHER		804	48040003	14804002-06001	CLUTCH SLIDER	
304	13040012		CLICK PAWL		805	48050005	14805002-0114	PINION GEAR YOKE	
400	44000031	1440000104907C	SPOOL ASSY		806	48060001	14806001-06	YOKE SPRING	
500	45000016	1450000204003	HANDLE ARM ASSY		807	48070005	14807002-0114	YOKE BRAKED PLATE	
516	45160006	14516001-0A913	HANDLE NUT RETAINER		808	48080003	14808002-06001	YOKE BRAKED PLATE SPRING	
600	46000009	14600002-04909	CAST CONTROL CAP		809	48090003	14809001-0170	CLUTCH BAR WASHER	
601	46010002	14601001-16	COMPRESSION SPRING		810	48100002	14810001-01001	CLUTCH SHAFT BUSHING	
603	46030002	14603001-01	O RING		812	48120001	14812001-06	BRAKED PLATE HOLDER	
604	16040002	11604002-01001	LEVER DRAG CLICK PAWL		9101	0910241	01051003-61	BALL BEARING	
604-1	46040005	14604003-01001	CONTROL CLICK		9103	0910163	01101612-62	BALL BEARING	3047
608	46080001	14608001-06	RETAINER		9103	0910170	01101612-63	BALL BEARING	
609	16090003	11609003-06001	DRAG SPRING WASHER	3105	9104	0910015	01050825-61	BALL BEARING	
609	16090009	11609003-06002	DRAG SPRING WASHER		9106	0910005	01031004-601	BALL BEARING	
609	46090009	14609003-05907	WASHER	3022	9107	0910024	01051104-601	BALL BEARING	
609-1	46090011	14609004-05907	WASHER	3030	9201	0920105	025.1x10.5x.2-6	WASHER	
610	16100018	11610004-006A	DRAG WASHER		9202	0920118	025x6.5x0.2-3	WASHER	
610-1	16100007	11610003-006	DRAG WASHER		9203	0920081	023x5x0.2-1	WASHER	
611	16110006	11611005-061	EARED WASHER		9204	0920292	025.9x12x0.2-6	WASHER	
612	16120028	11612007-06002	KEY WASHER		9205	0920014	0210x23.8.6-6	WASHER	
612-1	46120002	14612001-06001	KEY WASHER		9206	0920076	023.5x6x0.5-3	WASHER	
615	16150083	11615010-04002B	STAR DRAG		9207	0920067	022x4.9x0.3-3	WASHER	
618	46180001	14618001-07	WASHER		9302	0930684	03412.3x10.5-617	SCREW	
619	46190002	14619001-1	WASHER		9303	0930131	03212.6x6-61	SCREW	
700	47000006	14700002-0321	DRIVE GEAR		9306	0930429	03122x5-61	SCREW	
701	47010008	14701003-03002	DRIVE GEAR SHAFT		9402	29000002	12900002-06	E RETAINER	
702	47020005	1470200103004	PINION GEAR		9403	49000001	14900001-06	E RETAINER	
703	47030007	14703001-03001	WORM SHAFT GUARD		9404	29000001	12900001-06	E RETAINER	
703	47030008	14703001-06001	WORM SHAFT GUARD	3038	9504	19010001	11901001-06	C RETAINER	
704	47040007	14704001-16	LINE GUIDE SUPPORT BAR						