



ID - 400LX Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	41000263	1410001604004	BODY ASSY.		703	47030012	14703003-06001	WORM SHAFT GUARD	3038
105	41050002	14105001-0114	WORM SHAFT BUSHING		703	47030011	14703003-03001	WORM SHAFT GUARD	
117	41170001	14117001-03	NUT		704	47040011	14704003-16	LINE GUIDE SUPPORT BAR	
200	42000099	1420000404005	HANDLE SIDE PLATE	3050	705	47050006	14705002-06	TRANSMISSION GEAR	
202	42020001	14202001-06	RATCH	3045	708	47080003	14708001-0114	TRANSMISSION GEAR	
202	42020002	14202002-06001	RATCH		709	47090001	14709002-03	TRANSMISSION GEAR BUSHING	
206	42060003	14206002-01002	CONTROL PIN CAP		711	47110012	1471100111003	GUIDE SLIDE BASE ASSY	
216	42160003	14216001-061	ANTI-REV. PAWL SPRING	3006	712	47120005	14712003-03001	WORM SHAFT	
216	42160002	14216001-06002	ANTI-REV. PAWL SPRING		713	47130003	14713001-0170	LINE GUIDE PAWL CAP	
220	42200001	14220001-03907	SIDE PLATE HOLDED SCREW		715	17150008	11715003-06001C	LINE GUIDE PAWL	
221	42210001	14221001-07	O RING		720	17200002	11720002-06001	DRIVE GEAR SHAFT BUSHING	
222	42220004	14222002-01001	MAIN SIDE PLATE HOLDER		720	47200002	14720001-06001	DRIVE GEAR SHAFT BUSHING	3021
300	43000007	14300001-04912	SIDE PLATE		800	48000002	14800001-06	CLUTCH SHAFT	
302	43020002	14302001-03	WASHER		801	48010003	14801002-06001	CLUTCH SHAFT SPRING	
303	43030004	14303001-0170	CLICK BUTTON		802	48020014	14802004-01003	CLUTCH BAR	
304	13040012		CLICK PAWL		803	48030006	14803003-06	CLUTCH BAR SUPPORT	
304-1	43040001	14304001-06	CLICK PAWL		804	48040003	14804002-06001	CLUTCH SLIDER	
305	43050001	14305001-06	CLICK PAWL SPRING		805	48050005	14805002-0114	PINION GEAR YOKE	
306	43060001	14306001-03	CLICK PAWL SPRING		806	48060001	14806001-06	YOKE SPRING	
308	43080002	14308002-06001	CLICK BUTTON RETAINER		807	48070005	14807002-0114	YOKE BRAKED PLATE	
309	43090001	14309001-03907	CLICK PIN		808	48080003	14808002-06001	YOKE BRAKED PLATE SPRING	
400	44000080	1440000304907C	SPOOL ASSY.		809	48090003	14809001-0170	CLUTCH BAR WASHER	
401	44010001	14401001-0114	CLIKC GEAR		810	48100002	14810001-01001	CLUTCH SHAFT BUSHING	
500	45000016	1450000204003	HANDLE ARM ASSY		812	48120001	14812001-06	BRAKED PLATE HOLDER	
516	45160006	14516001-0A913	HANDLE NUT RETAINER		9101	0910241	01051003-61	BALL BEARING	
600	46000009	14600002-04909	CAST CONTROL CAP		9103	0910163	01101612-62	BALL BEARING	3047
601	46010002	14601001-16	COMPRESSION SPRING		9103	0910170	01101612-63	BALL BEARING	
603	46030002	14603001-01	O RING		9104	0910015	01050825-61	BALL BEARING	
604	16040002	11604002-01001	LEVER DRAG CLIKC PAWL		9106	0910005	01031004-601	BALL BEARING	
604-1	46040005	14604003-01001	CONTROL CLIKC		9107	0910024	01051104-601	BALL BEARING	
608	46080001	14608001-06	RETAINER		9201	0920105	025.1x10.5x.2-6	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER	3105	9202	0920118	025x6.5x0.2-3	WASHER	
609	16090009	11609003-06002	DRAG SPRING WASHER		9203	0920081	023x5x0.2-1	WASHER	
609	46090009	14609003-05907	WASHER	3022	9204	0920292	025.9x12x0.2-6	WASHER	
609-1	46090011	14609004-05907	WASHER	3030	9205	0920014	0210x23.8.6-6	WASHER	
610	16100018	11610004-006A	DRAG WASHER		9206	0920076	023.5x6x0.5-3	WASHER	
610-1	16100007	11610003-006	DRAG WASHER		9207	0920067	022x4.9x0.3-3	WASHER	
611	16110006	11611005-061	EARED WASHER		9302	0930224	03412.3x10.5-61	SCREW	
612	16120028	11612007-06002	KEY WASHER		9303	0930131	03212.6x6-61	SCREW	
612-1	46120002	14612001-06001	KEY WASHER		9305	0930226	03412.6x4-61	SCREW	
615	16150083	11615010-04002B	STAR DRAG		9306	0930429	03122x5-61	SCREW	
618	46180001	14618001-07	WASHER		9312	0930244	03412.6x9-61	SCREW	
619	46190001	14619001-03	WASHER		9402	29000002	12900002-06	E RETAINER	
700	47000006	14700002-0321	DRIVE GEAR		9403	49000001	14900001-06	E RETAINER	
701	47010008	14701003-03002	DRIVE GEAR SHAFT		9404	29000001	12900001-06	E RETAINER	
702	47020005	1470200103004	PINION GEAR		9504	19010001	11901001-06	C RETAINER	