



Integrity 7/8b PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	3100059	Body assy. (with main shaft)	408	3408014	Spool retainer
102	3102008	Reel foot	409	3409001	Spool retainer spring
111	3111006	Click pawl	410	34100018	Spool cover assy.
117	3117002	Holder plate	413	34130004	Counter balance
209	3209001	Waveform washer	416	34160009	Bearing bushing
300	33000118	Drag knob	420	3420001	Handle knob bushing
304	33040028	Click pawl	910	0910170	One way bearing
310	3310006	Cord drag washer	920	0920033	Washer
310-1	33100012	Cord drag washer	920	0920063	Washer
315	3315006	Disk break	920	0920149	Washer
321	3321006	Main shaft bushing	930	0930009	Screw
340	3340001	Drag washer retainer	930	0930011	Screw
400	34000354	Spool assy.	930	0930077	Screw
400-1	34000336	Spool	930	0930084	Screw
404	3404030	Handle knob	930	0930117	Screw
405	3405008	Handle knob screw	930	09301143	Screw

309OKM01702081