



I - 8/9 Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	31000457	13100033-04703	MAIN BODY		404	34040014	13404010-001	HANDLE KNOB	
100	31000461	13100033-04905	MAIN BODY	2925	405	34050008	13405005-03907	HANDLE KNOB SCREW	
101	31010032	13101020-06001	MAIN SHAFT		408	34080006	13408007-05907	SPOOL RETAINER	
102	31020046	13102008-04007	BODY FOOT		409	34090001	13409001-06	SPOOL RETAINER SPRING	
102	31020037	13102008-04001	BODY FOOT	2922	410	34100018	1341000601001	SPOOL COVER ASSY.	
111	31110005	13111006-06	CLICK PAWL	2912	410	34100024	13410008-04703	SPOOL COVER	3035
111	31110006	13111006-06001	CLICK PAWL		410	34100027	13410008-04905	SPOOL COVER	2925
117	31170002	13117002-01	FIXED PLATE		413	34130009	13413004-03907	COUNTER BALANCE	
209	32090001	13209001-05001	WASHER		416	34160005	13416003-01	ONE WAY BEARING BUSHING	
209	32090002	13209001-05907	SPRING WASHER	2918	420	34200001	13420001-03907	HANDLE KNOB BUSHING	
300	33000049	13300020-04005	DRAG KNOB		9101	0910173	01101612-63A	ONE WAY BEARING ASSY.	
300	33000053	13300020-04905	DRAG KNOB	2925	9101	0910169	01101612-62A	ONE WAY BEARING ASSY.	3043
304	33040012	13304009-06	CLICK PAWL		9201	0920033	0212x19.8x0.5-9	WASHER	
310	33100004	13310003-006	DRAG WASHER	2902	9201-1	0920063	0221x33x1-12	WASHER	
310-1	33100010	13310004-006	DRAG WASHER	2902	9202	0920149	028.1x12x0.1-6	WASHER	
310	33100006	13310003-01	CORK DRAG WASHER		9302	0930117	03212.0x5.0-61	SCREW	
310-1	33100012	13310004-01	CORK DRAG WASHER		9303	0930084	032100510	SCREW	
315	33150006	13315004-06	DISK BREAK		9303	0930143		SCREW	3022
315	33150009	13315004-0661	DISK BREAK	2912	9304	0930084	032100510	SCREW	
321	33210006	13321005-06001	MAIN SHAFT BUSHING		9304	0930143		SCREW	3026
340	33400001	13340001-04909	DRAG WASHER RETAINER		9306	0930257	03414x5-061	SCREW	
400	34000365	13400037-04703	SPOOL		9307	0930009	03112x2-61	SCREW	
400	34000366		SPOOL	3047	9309	0930011	03112x5-61	SCREW	
400	34000371	13400037-049051	SPOOL	2925					