
okuma



KDS-364LX PARTS LIST

Key no	Part name	PART NUMBER KDS-364LX	Key no	Part name	PART NUMBER KDS-364LX	Key no	Part name	PART NUMBER KDS-364LX
1	Tension Knob	5K201010	34	Retainer	6K772101	67	Screw	6K398603
2	Washer	6K709201	35	Worm Shaft Assembly	5K216301	68	Gear Metal	5K213202
3	Washer	6K164601	36	Coil Spring	5K337001	69	Ratchet	5K213601
4	Washer	6K164605	37	Front Support	5K217210	70	Washer	5K235101
5	O-Ring	6K904901	38	Screw	63511112	71	Drive Gear	5K213706
6	Thumb Screw	5K214401	39	Pillar	5K212501	72	Washer-L	5K238301
7	Washer	6K204604	40	Frame Assembly	5K216728	73	Washer-D	5K238501
8	Gear Side Cover Assembly (One Way Clutch)	5K217320	41	Clutch Link	5K213001	74	Washer-A	5K238401
9	Coil Spring	5K255501	42	Thumb Bar	5K212701	75	Washer-D	5K238601
10	Ball Bearing	6K304004	43	Tap Screw	6K395601	76	Sleeve	6K896718
11	Ring	6K170701	44	Spool Assembly (1 ball bearing)	5K214722	77	Washer	6K177302
12	Pinion	5K213504	45	Retainer	63201402	78	Leaf Spring Assembly	6K259201
13	Clutch	5K390301	46	Ball Bearing	5K126106	79	Spring Washer	5K027201
14	Screw	6K723501	47	Spool Pinion	5K215101	80	Du-Washer	5K174201
15	Cam Plate	5K212901	48	Retainer	6B339801	81	Star Drag Assembly	5K0840C3
16	Clutch Cam	5K217101	49	Washer	6K164605	82	Washer	5K199101
17	Kick Lever	5K216901	50	Screw	63535902	83	Handle Arm Assenbly	5K231511
18	Spring	5K217001	51	Spool Cover Assembly	5K217901	84	Washer	5K181817
19	Spring	5K218101	52	Collar	5K216001	85	Handle Knob Assembly	5K005001
20	Stopper Assembly	5K214502	53	Gear	6K163501	86	Washer	63520406
21	Screw	6K314101	54	Washer	6B924906	87	Screw	5K201601
22	Screw	6K311306	55	Tap Screw	6K787601	88	Handle Knob Cap	5K201501
23	Lever Wind Assembly	5K212201	56	Click Leaf Spring	5K216102	89	Nut	5K201401
24	Bush	5K028501	57	Screw	6K494001	90	Retainer	6K394501
25	Washer	6K161803	58	Palm Side Cover	5K230311	91	Screw	5K201301
26	Retainer	63205901	59	Retainer	63205901	92	Coil Spring	5K201201
27	Lever Wind Pin	6K256506	60	Washer	6K164404	93	Click Pin	5K234901
28	Washer	6K148803	61	Click Claw	5K215601	94	Click Plate	6K797201
29	Lever Wind Nut	6K704403	62	Washer	6K148904	95	Retainer	5K129201
30	Ball Bearing	6K626404	63	Click Lever	5K215702	96	Ring	6K177301
31	Pipe	5K212101	64	Retainer	63205901	97	Control Plate	5K231207
32	Ball Bearing	6K304004	65	Ball Bearing	6K170604	98	Plate	63511816
33	Washer	6E096503	66	Bearing Plate	5K213301	99	Screw	5K154621