



MA-20DLXT PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001960	Main body assy	710	17100040	Line guide assy.
105	11050007	Worm shaft bushing	712	17120096	Worm shaft
105-1	11050006	Worm shaft bushing	713	17130002	Line guide pawl cap
117	11170012	Retainer nut	715	17150009	Line guide pawl
200	12002082	Handle side plate	800	18000018	Clutch shaft
201	12010026	Anti-re pawl	801	18010011	Clutch spring
204	12040016	Compression spring	802	18020156	Clutch bar
207	12070099	Holed plate	804	18040010	Clutch slider
211	12110009	Anti-re pawl pin	805	18050006	Pinion gear yoke
212	12120095	Counter cover assy	806	18060003	Yoke spring
215	12150015	Hold plate bushing	807	18070002	Yoke braked plate
215-1	12150029	Hold plate bushing	910	19100145	Depth counter assy
216	12160005	Anti-re pawl spring	29000001	29000001	E retainer
300	13000613	Vice side plate	29000006	29000006	C retainer
302	13020002	Washer	19000002	19000002	E retainer
303	13030048	Click button	0910099	0910099	Ball bearing
304	13040001	Click pawl	0910227	0910227	Ball bearing
305	13050007	Click pawl spring	0920111	0920111	Washer
400	14000308	Spool assy.	0920114	0920114	Washer
401	14010053	Spool click gear	0920126	0920126	Washer
500	15000466	Handle assy.	0920282	0920282	Washer
516	15160002	Handle nut retainer	0920076	0920076	Washer
600	16000039	Cast control cap	0920332	0920332	Washer
609	16090003	Drag spring washer	0920085	0920085	Washer
610	16100038	Drag washer	0920066	0920066	Washer
610-1	16100045	Drag washer	0920160	0920160	Washer
610-2	16100055	Drag washer	0920315	0920315	Washer
611	16110005	Eared washer	0930747	0930747	Screw
612	16120027	Key washer	0930058	0930058	Screw
612-3	26120056	Key washer	0930210	0930210	Screw
614	16140003	Drag washer	0930732	0930732	Screw
615	16150010	Star darg	0930609	0930609	Screw
617	16170002	Drive gear shaft bushing	0930196	0930196	Screw
618	16180002	Washer	0930219	0930219	Screw
700	17000213	Drive gear	0930426	0930426	Screw
701	17010196	Drive gear shaft assy.	0930618	0930618	Screw
702	17020329	Pinion gear assy.	0930438	0930438	Screw
703	17030008	Worm shaft guard	0930298	0930298	Screw
704	17040012	Line guide support bar	0930626	0930626	Screw
705	17050016	Transmission gear	0930226	0930226	Screw
707	17070011	Transmission gear	0940025	0940025	O ring
708	17080003	Transmission gear			