



MA-20DXT PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001960	Main body assy	710	17100040	Line guide assy.
105	11050013	Worm shaft bushing	712	17120092	Worm shaft
105-1	11050007	Worm shaft bushing	713	17130002	Line guide pawl cap
117	11170012	Retainer nut	715	17150009	Line guide pawl
200	12002081	Handle side plate	800	18000008	Clutch shaft
201	12010011	Anti-re pawl	801	18010001	Clutch spring
207	12070098	Holded plate	802	18020155	Clutch bar
211	12110009	Anti-re pawl pin	804	18040013	Clutch cam slider
212	12120095	Counter cover assy	805	18050002	Pinion gear yoke
215	12150015	Hold plate bushing	806	18060003	Yoke spring
215-1	12150029	Hold plate bushing	910	19100145	Depth counter assy
216	12160001	Anti-re pawl spring	29000001	29000001	E retainer
300	13000612	Vice side plate	29000006	29000006	C retainer
302	13020002	Washer	19000002	19000002	E retainer
303	13030042	Click button	0910099	0910099	Ball bearing
304	13040001	Click pawl	0910227	0910227	Ball bearing
305	13050007	Click pawl spring	0920283	0920283	Washer
400	14000304	Spool assy.	0920114	0920114	Washer
401	14010051	Spool click gear	0920162	0920162	Washer
500	15000466	Handle assy.	0920126	0920126	Washer
516	15160002	Handle nut retainer	0920076	0920076	Washer
600	16000038	Cast control cap	0920332	0920332	Washer
609	16090003	Drag spring washer	0920066	0920066	Washer
610	16100038	Drag washer	0920480	0920480	Washer
610-1	16100045	Drag washer	0920282	0920282	Washer
610-2	16100055	Drag washer	0920370	0920370	Washer
611	16110005	Eared washer	0920573	0920573	Washer
612	16120027	Key washer	0930058	0930058	Screw
612-1	16120029	Key washer	0930210	0930210	Screw
614	16140003	Drag washer	0930732	0930732	Screw
615	16150202	Star darg	0930609	0930609	Screw
617	16170002	Drive gear shaft bushing	0930196	0930196	Screw
618	16180002	Washer	0930426	0930426	Screw
700	17000211	Drive gear	0930202	0930202	Screw
701	17010278	Drive gear shaft assy	0930438	0930438	Screw
702	17020310	Pinion gear assy.	0930298	0930298	Screw
703	17030008	Worm shaft guard	0930626	0930626	Screw
704	17040012	Line guide support bar	0930219	0930219	Screw
705	17050011	Transmission gear	0930226	0930226	Screw
707	17070009	Transmission gear	0930747	0930747	Screw
708	17080003	Transmission gear	0940025	0940025	O ring

109OKA08001101