



MK-130II SEa PARTS LIST

Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME
100	11001659	Main body assy.	507-2	15070028	Clutch shift drive pin	901	19010022	C type retainer
100-1	11001994	Main body	508	15080002	Push button spring	901	19010023	C type retainer
102	11020098	Reel foot	509	15090076	Handle knob	902	19020002	Tool assy
102-1	11020097	Reel foot gasket	510	15100111	Handle Pin	910	09101111	Thrust bearing assy.
108	11080024	Hangers	512	15120093	Handle knob cover	910	0910444	Ball bearing
114	11140056	Reel clamp assy.	513	15130032	Handle cover	910	0910449	Ball bearing
114-1	11140076	Reel clamp	515	15150002	Handle nut retainer screw	910	0910450	Ball bearing
115	11150028	Clamp screw	516	15160041	Handle nut retainer	913	19130007	Waved washer
116	11160014	Reel clamp nuts	516-1	15160038	Handle nut retainer assy.	920	0920025	Washer
117	11170027	Hexagon nut	516-2	15160033	Handle nut retainer	920	0920093	Washer
117-1	11170025	Hexagon nut	517	15170029	Clutch shift pin assy.	920	0920115	Washer
200	12002022	Main side plate	600	16000171	Cast control cap assy.	920	0920341	Washer
201	12010066	Anti-re pawl assy.	602	16020038	Adjustable block	920	0920427	Washer
201-1	12010067	Anti-re pawl assy.	605	16050215	Lever drag assy.	920	0920587	Washer
202	12020042	Ratchet	605-1	16050105	Lever side chip	920	0920450	Washer
203	12030004	Control pin	605-3	16050220	Lever drag assy.	920	0920473	Washer
204	12040002	Compression spring	607	16070073	Pinion guard	920	0920479	Washer
204-1	12040025	Compression spring	608	16080007	C type retainer	920	0920486	Washer
204-2	12040027	Compression spring	608-1	16080020	Drag washer retainer	920	0920507	Washer
204-3	12040035	Compression spring	609	16090014	Main shaft spring washer	920	09201008	Washer
204-4	12040023	Compression spring	609-1	16090015	Main shaft spring washer	930	0930032	Screw
205	12050050	Decoration plate	610	16100073	Drag washer	930	0930075	Screw
206	12060011	Stopper cap	611	16110064	Eared washer	930	09301116	Screw
207	12070088	Holder plate	612	16120088	Key washer	930	09301117	Screw
211	12110026	Anti-re pawl pin	612-1	16120089	Key washer	930	09301118	Screw
215	12150028	Holed plate bushing	620	16200002	Drag cam bushing	930	09301119	Screw
217	12170038	Anti-re pawl spring	622	16220026	Top cover for star drag	930	09301124	Screw
219	12190035	Bushing	623	16230014	Under cover for star drag	930	09301152	Screw
226	12260003	Ceramic ball	700	17000463	H.S. main gear/pinion gear set	930	09301381	Screw
242	12420002	Compression spring	700	17000462	L.S. main gear/pinion gear set	930	09301413	Screw
300	13000617	Vice side plate	701	17010313	Drive gear shaft	930	09301414	Screw
303	13030077	Click button assy.	717	17170014	Main shaft pin	930	0930211	Screw
304	13040008	Click pawl	718	17180359	Main shaft	930	0930229	Screw
400	14001081	Spool assy	723	17230040	Silent spring bushing	930	0930532	Screw
401	14010038	Spool click gear	723-1	17230039	R/ side silent spring	930	0930605	Screw
405	14050045	Spool cover	723-2	17230038	L/ side silent spring	940	0940027	O ring
500	15000472	Handle arm assy.	726	17260008	Drive gear bushing	PA1115	PA1115	Oil tank
500-1	15000471	Handle arm	900	19000009	E type retainer			
501	15010010	Handle nut	900	29000001	E type retainer			
507	15070038	Push button assy.	901	19010015	C type retainer			

109OKM03921301