



MK-16II-SEA PARTS LIST

Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME
100	11001853	Main body assy.	507-2	15070013	Clutch shift drive pin	910	0910443	Ball bearing
100-1	11001962	Main body	508	15080002	Push button spring	910	0910474	Ball bearing
102	11020051	Reel foot	509	15090074	Handle knob	910	0910502	Bearing
102-1	11020058	Reel foot gasket	510	15100110	Handle knob rivet	910	0910503	Bearing
108	11080032	Hangers	512	15120087	Handle knob cover	912	19120028	Cover plate
108-1	11080031	Hangers	513	15130024	Handle arm cap	913	19130008	Waved spring
114	11140068	Reel clamp assy.	515	15150002	Handle arm screw	920	0920004	Washer
114-1	11140050	Reel clamp	516	15160041	Handle nut retainer	920	0920025	Washer
115	11150027	Reel clamp screws	516-1	15160038	Handle nut retainer assy.	920	0920154	Washer
116	11160015	Reel clamp nuts	516-2	15160033	Handle nut retainer	920	0920411	Washer
117	11170027	Hexagon nut	517	15170021	Compression assy.	920	0920427	Washer
117-1	11170026	Hexagon nut	600	16000166	Cast control cap assy.	920	0920440	Washer
200	12001201	Handle side plate assy.	602	16020040	Adjustable block	920	0920441	Washer
201	12010074	Anti-re pawl assy.	605	16050144	Lever drag assy.	920	0920455	Washer
201-1	12010075	Anti-re pawl assy.	605-1	16050096	Lever side chip	920	0920479	Washer
202	12020022	Ratchet	605-3	16050246	Lever drag assy.	920	0920496	Washer
203	12030004	Control pin	607	16070080	Pinion guard	920	0920509	Washer
204	12040002	Compression spring	608	16080012	C type retainer	920	09201007	Washer
204-1	12040025	Compression spring	609	16090019	Main shaft spring washer	930	09301095	Screw
204-2	12040027	Compression spring	609-1	16090021	Main shaft spring washer	930	09300075	Screw
204-3	12040041	Compression spring	611	16110063	Eared washer	930	09300084	Screw
204-4	12040023	Compression spring	612-1	16120085	Key washer	930	0930211	Screw
205	12050039	Decoration plate	612-2	16120086	Key washer	930	0930532	Screw
206	12060011	Stopper cap	620	16200001	Drag cam bushing	930	0930605	Screw
207	12070125	Holder plate	622	16220019	Top cover for star drag	930	09301117	Screw
211	12110014	Anti-re pawl pin	623	16230012	Under cover for star drag	930	09301124	Screw
215	12150012	Holed plate bushing	700	17000452	H.S. main gear/pinion gear set	930	09301193	Screw
217	12170037	Anti-re pawl spring	700-1	17000453	L.S. main gear/pinion gear set	930	09301194	Screw
226	12260003	Ceramic ball	701	17010296	Drive gear shaft	930	09301195	Screw
242	12420007	Compression spring	717	17170013	Main shaft pin	930	09301197	Screw
300	13001115	Vice side plate	718	17180347	Main shaft	930	09301201	Screw
303	13030075	Click knob assy.	723	17230035	Silent spring bushing	930	09301213	Screw
304	13040030	Click pawl	723-1	17230034	R/ side silent spring	930	09301334	Screw
400	14000993	Spool assy.	723-2	17230037	L/ side silent spring	930	09301415	Screw
401	14010043	Spool click gear	900	19000004	E type retainer	940	09400025	O ring
405	14050042	Water proof cover	900	29000001	E type retainer	PA1115	PA1115	Oil tank
500	15000336	Handle arm assy.	901	19010006	C type retainer			
500-1	15000374	Handle arm	901	19010022	C type retainer			
501	15010010	Handle nut	902	19020002	Tool			
507	15070039	Push button assy.	910	0910410	Thrust bearing assy.			

109OKM06402161