



MK-30II-Sea PARTS LIST

Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME
100	11004850	Main body assy.	507-2	15070013	Clutch shift drive pin	902	19020002	Tool
100-1	11004849	Main body	508	15080002	Push button spring	910	0910410	Thrust bearing assy.
102	11020051	Reel foot	509	15090076	Handle knob	910	0910443	Ball bearing
102-1	11020058	Reel foot gasket	510	15100111	Handle Pin	910	0910474	Ball bearing
108	11080025	Hangers	512	15120093	Handle knob cover	910	0910502	Ball bearing
108-1	11080028	Hangers	513	15130024	Handle arm cap	910	0910503	Ball bearing
114	11140067	Reel clamp assy.	515	15150002	Handle nut retainer screw	913	19130008	Waved spring
114-1	11140050	Reel clamp	516	15160041	Handle nut retainer	920	0920004	Washer
115	11150027	Clamp screw	516-1	15160038	Handle nut retainer assy.	920	0920025	Washer
116	11160015	Reel clamp nuts	516-2	15160033	Handle nut retainer	920	0920154	Washer
117	11170027	Hexagon nut	517	15170027	Compression assy.	920	0920411	Washer
117-1	11170026	Hexagon nut	600	16000103	Cast control cap assy.	920	0920440	Washer
200	12001995	Handle side plate assy.	602	16020040	Adjustable block	920	0920441	Washer
201	12010049	Anti-re pawl assy.	605	16050124	Drag lever assy.	920	0920455	Washer
201-1	12010050	Anti-re pawl assy.	605-1	16050096	Lever side chip	920	0920473	Washer
202	12020022	Ratchet	605-3	16050231	Lever drag assy	920	0920479	Washer
203	12030004	Strike Button	607	16070080	Pinion guard	920	0920486	Washer
204	12040002	Compression spring	608	16080012	C type retainer	920	0920496	Washer
204-1	12040025	Compression spring	609	16090019	Belville washers	920	0920509	Washer
204-2	12040027	Compression spring	609-1	16090021	Belville washers	920	09201008	Washer
204-3	12040041	Compression spring	611	16110053	Drag eared washer	930	0930075	Screw
204-4	12040023	Compression spring	612	16120077	Key washer	930	0930084	Screw
205	12050046	Decoration plate	612-1	16120078	Key washer	930	0930211	Screw
206	12060011	Lever drag stopper cap	620	16200001	Drag cam bushing	930	0930532	Screw
207	12070086	Holder plate	622	16220021	Drag lever cover	930	0930605	Screw
211	12110014	Anti-re pawl pin	623	16230012	Drag lever cover bushing	930	09301117	Screw
215	12150012	Holdd plate bushing	700	17000448	H.S. main gear/pinion gear set	930	09301124	Screw
217	12170037	Anti-re pawl spring	700-1	17000357	Low speed drive gear	930	09301152	Screw
226	12260003	Ceramic ball	701	17010315	Drive gear shaft	930	09301193	Screw
242	12420007	Compression spring	702-1	17020424	Low speed pinion gear	930	09301194	Screw
300	13001096	Vice side plate	717	17170013	Main shaft pin	930	09301195	Screw
303	13030075	Click button assy.	718	17180216	Main shaft	930	09301197	Screw
304	13040021	Click pawl	723	17230027	Silent spring bushing	930	09301201	Screw
400	14000164	Spool assy.	723-1	17230032	R/ side silent spring	930	09301213	Screw
401	14010037	Spool click gear	723-2	17230033	L/ side silent spring	930	09301220	Screw
405	14050037	Water proof cover	900	19000004	E type retainer	930	09301334	Screw
500	15000391	Handle arm assy.	900	29000001	E type retainer	930	09301415	Screw
500-1	15000390	Handle arm	901	19010006	C type retainer	940	0940027	O ring
501	15010010	Handle nut	901	19010012	C type retainer	PA1115	PA1115	Oil tank
507	15070039	Push button assy.	901	19010022	C type retainer			

109OKM03902301