



MK- 30II

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001700	Main body assy.	507-2	15070013	Clutch shift drive pin	901	19010022	C type retainer
100-1	11001544	Main body	508	15080002	Push button spring	902	19020002	Tool assy
102	11020051	Reel foot	509	15090074	Handle knob	910	0910410	Thrust bearing assy.
102-1	11020058	Reel foot gasket	510	15100110	Handle knob rivet	910	0910441	Ball bearing
108	11080025	Hangers	512	15120087	Handle knob cover	910	0910443	Ball bearing
114	11140051	Reel clamp assy.	513	15130030	Handle arm cap	910	0910448	Ball bearing
114-1	11140050	Reel clamp	515	15150002	Handle nut retainer screw	910	0910474	Ball bearing
115	11150027	Clamp screw	516	15160034	Handle nut retainer	913	19130008	Waved spring
116	11160015	Reel clamp nuts	516-1	15160038	Handle nut retainer assy.	920	0920004	Washer
117	11170027	Hexagon nut	516-2	15160033	Handle nut retainer	920	0920025	Washer
117-1	11170026	Hexagon nut	517	15170021	Compression assy.	920	0920154	Washer
200	12001926	Handle side plate assy.	600	16000103	Cast control cap assy.	920	0920411	Washer
201	12010049	Anti-re pawl assy.	602	16020040	Adjustable block	920	0920427	Washer
201-1	12010050	Anti-re pawl assy.	605	16050117	Lever drag assy	920	0920440	Washer
202	12020022	Ratchet	605-1	16050096	Lever side chip	920	0920441	Washer
203	12030004	Control pin	605-3	16050230	Lever drag assy.	920	0920455	Washer
204	12040002	Compression spring	607	16070080	Pinion guard	920	0920479	Washer
204-1	12040025	Compression spring	608	16080012	C type retainer	920	0920496	Washer
204-2	12040027	Compression spring	609	16090019	Main shaft spring washer	930	0920509	Washer
204-3	12040035	Compression spring	609-1	16090021	Main shaft spring washer	930	09201007	Washer
204-4	12040023	Compression spring	611	16110053	Eared washer	930	0930075	Screw
205	12050046	Decoration plate	612	16120077	Key washer	930	0930084	Screw
206	12060011	Stopper cap	612-1	16120078	Key washer	930	0930211	Screw
207	12070086	Holder plate	620	16200001	Drag cam bushing	930	0930532	Screw
211	12110014	Anti-re pawl pin	622	16220021	Top cover for star drag	930	0930605	Screw
215	12150012	Holded plate bushing	623	16230012	Under cover for star drag	930	09301117	Screw
217	12170037	Anti-re pawl spring	700	17000448	H.S. main gear/pinion gear s	930	09301124	Screw
226	12260003	Ceramic ball	700-1	17000369	Low speed drive gear	930	09301193	Screw
242	12420007	Compression spring	701	17010315	Drive gear shaft	930	09301195	Screw
300	13000977	Vice side plate	702-1	17020436	Low speed pinion gear	930	09301201	Screw
303	13030075	Click button assy.	717	17170013	Main shaft pin	930	09301213	Screw
304	13040021	Click pawl	718	17180216	Main shaft	930	09301220	Screw
400	14000810	Spool assy.	723	17230027	Silent spring bushing	930	09301334	Screw
401	14010037	Click Gear	723-1	17230014	R/ side silent spring	930	09301415	Screw
405	14050037	Water proof cover	723-2	17230012	L/ side silent spring	940	0940025	O ring
500	15000059	Handle arm assy.	900	19000004	E type retainer	PA1115	PA1115	Oil tank
500-1	15000047	Handle arm	900	29000001	E type retainer			
501	15010010	Handle nut	901	19010006	C type retainer			
507	15070039	Push button assy.	901	19010012	C type retainer			