



## MK-8II PARTS LIST

Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME	Key no	PARTS NO	PARTS NAME
100	11001828	Main body assy.	507-2	15070013	Clutch shift drive pin	902	19020002	Tool assy
100-1	11001826	Main body	508	15080002	Push button spring	910	0910430	Thrust bearing assy.
102	11020064	Reel foot	509	15090077	Handle knob	910	0910446	Ball bearing
102-1	11020057	Reel foot gasket	510	15100110	Handle knob rivet	910	0910447	Ball bearing
108	11080022	Hangers	512	15120098	Handle knob cover	910	0910472	Ball bearing
108-1	11080023	Hangers	513	15130029	Handle arm cap	912	19120020	Cover plate
114	11140064	Reel clamp assy.	515	15150002	Handle nut retainer screw	920	0920025	Washer
114-1	11140060	Reel clamp	516	15160034	Handle nut retainer	920	0920029	Washer
115	11150030	Clamp screw	516-1	15160038	Handle nut retainer assy.	920	0920079	Washer
116	11160017	Reel clamp nuts	516-2	15160033	Handle nut retainer	920	0920126	Washer
200	12001925	Handle side plate assy.	517	15170020	Compression assy.	920	0920283	Washer
201	12010046	Anti-re pawl	600	16000102	Cast control cap assy.	920	0920304	Washer
202	12020024	Ratchet	601	16010009	Compression spring	920	0920412	Washer
203	12030008	Control pin	602	16020039	Adjustable block	920	0920423	Washer
204	12040021	Compression spring	605	16050115	Lever drag assy.	920	0920427	Washer
204-2	12040028	Compression spring	605-1	16050090	Lever side chip	920	0920441	Washer
204-3	12040035	Compression spring	605-3	16050224	Lever drag assy.	920	0920454	Washer
204-4	12040032	Compression spring	607	16070081	Pinion guard	920	0920496	Washer
205	12050025	Decoration plate	608	16080012	C type retainer	920	0920509	Washer
206	12060011	Stopper cap	609	16090022	Main shaft spring washer	920	09201007	Washer
207	12070089	Holder plate	609-1	16090016	Main shaft spring washer	930	0930086	Screw
209	32090003	Waved washer	611	16110054	Eared washer	930	0930096	Screw
211	12110015	Anti-re pawl pin	612	16120076	Key washer	930	0930211	Screw
215	12150012	Holed plate bushing	620	16200003	Drag cam bushing	930	0930472	Screw
216	12160008	Extension Spring	622	16220020	Top cover for star drag	930	0930511	Screw
217	12170035	Anti-re pawl spring	623	16230015	Under cover for star drag	930	0930532	Screw
226	12260003	Ceramic ball	700	17000447	H.S. main gear/pinion gear set	930	0930605	Screw
300	13001026	Vice side plate assy.	700	17000459	L.S. main gear/pinion gear set	930	09301052	Screw
300-1	13000336	Vice side plate assy.	701	17010317	Drive gear shaft	930	09301117	Screw
303	13030071	Click knob	717	17170013	Main shaft pin	930	09301124	Screw
304	13040017	Click pawl	718	17180338	Main shaft	930	09301167	Screw
305	13050013	Click pawl spring	723	17230026	Silent spring bushing	930	09301196	Screw
400	14000946	Spool assy	723-1	17230021	R/ side silent spring	930	09301219	Screw
401	14010034	Spool click gear	723-2	17230019	L/ side silent spring	940	0940025	O ring
405	14050040	Water proof cover	900	29000001	E type retainer	PA1115	PA1115	Oil tank
500	15000090	Handle arm assy.	900	19000005	E type retainer			
500-1	15000322	Handle arm	901	19010006	C type retainer			
501	15010010	Handle nut	901	19010012	C type retainer			
507	15070039	Push button assy.	901	19010022	C type retainer			