



NMS-2000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004870	Main body	700	27000446	Drive gear
105-1	21056618	Pinion bearing fixed bushing	702	27020958	Pinion gear
105-2	21056616	Pinion bearing fixed bushing	705	27050220	Transmission gear
108	21081731	Cap	708	27080190	Oscillating slider
200	22004681	Side plate	716	27160016	Oscillation slider plate
300	23005235	Rotor	718	27180804	Main shaft
301	23015023	Bail arm	719	27190029	Click gear
304	23042891	Bail arm cover	722	27220009	Click gear washer
305	23050235	Kick lever	800	28000332	Anti-reverse/anti-re lever
307	23071929	Bail holder	800-1	28000402	Anti-reverse/anti-re lever
309	23090002	Bail arm slider	801	28010024	Anti-re lever spring
310	23100005	Compression spring	0910618	0910618	One way assy.
313	23133481	Bail wire assy.	0910215	0910215	Ball bearing
315	23150086	Line roller	0910049	0910049	Ball bearing
316	23160014	Line roller bushing	0910039	0910039	Ball bearing
317	23170014	Line roller washer	0910335	0910335	Ball bearing
318	23180006	Rotor nut	0920590	0920590	Washer
400	240017097	Spool assy.	0920136	0920136	Washer
405	24050042	Drag washer retainer	0930058	0930058	Screw
407	24070047	Extension spring	0930541	0930541	Screw
412	24120038	Spool bushing	0930641	0930641	Screw
500	25007082	Handle assy.	0930964	0930964	Screw
513	25130915	Handle cap	09301327	09301327	Screw
515	25150002	Handle screw cap washer	0930209	0930209	Screw
600	26004718	Drag knob assy.	09301262	09301262	Screw
610	26100011	Drag washer	09301454	09301454	Screw
612	26120003	Key washer	0930431	0930431	Screw
612-1	26120054	Key washer	0930838	0930838	Screw