



NMS-3000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21007510	Main body	705	27050143	Transmission gear
105	21050012	Pinion bearing fixed plate	708	27080121	Oscillating slider
105-1	21056571	Pinion bearing fixed plate	716	27160016	Oscillation slider plate
105-2	21056610	Pinion bearing fixed bushing	718	27180732	Main shaft
108	21087140	Cap	719	27190029	Click gear
200	22007336	Side plate	722	27220009	Click gear washer
300	23005266	Rotor	800	28000437	Anti-reverse/anti-re lever
301	23015024	Bail arm	800-1	28000324	Anti-reverse/anti-re lever
304	23042877	Bail arm cover	801	28010024	Anti-re lever spring
305	23050220	Kick lever	0910648	0910648	Ball bearing
307	23071930	Bail holder	0910039	0910039	Ball bearing
309	23090002	Bail arm slider	0910215	0910215	Ball bearing
310	23100005	Compression spring	0910049	0910049	Ball bearing
313	23131830	Bail wire assy.	0910091	0910091	Ball bearing
315	23150086	Line roller	0910335	0910335	Ball bearing
316	23160014	Line roller bushing	0920310	0920310	Washer
317	23170014	Line roller washer	0920590	0920590	Washer
318	23180006	Rotor nut	0920151	0920151	Washer
400	240016926	Spool assy.	0920237	0920237	Washer
405	24050042	Drag washer retainer	0930058	0930058	Screw
407	24070047	Extension spring	0930541	0930541	Screw
412	24120054	Spool bushing	09301462	09301462	Screw
500	25007025	Handle assy.	09301538	09301538	Screw
513	25130904	Handle cap	0930438	0930438	Screw
515	25150002	Handle screw cap washer	0930471	0930471	Screw
600	26004718	Drag knob assy.	0930209	0930209	Screw
610	26100011	Drag washer	09301262	09301262	Screw
611	26110004	Eared washer	09301450	09301450	Screw
612	26120003	Key washer	0930431	0930431	Screw
700	27000240	Drive gear	0930838	0930838	Screw
702	27020932	Pinion gear			