



RAW-II 463 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	31000756	Frame assy.(with shaft)	400	34000798	Spool
102	31020169	Reel foot	404	34040027	Handle knob
104	31040052	Spool holder knob	405	34050016	Handle knob rivet
115	31150005	Bushing for Click pawl	406	34060002	Retainer spring
207	32070006	Handle knob spacer	410	34100067	Spool cover
300	33000119	Drag lever	425	34250004	Silent spring
303	33030010	drag washer holder plate	910	0910438	Ball bearing
304-1	33040029	Click pin	920	0920450	Washer
304-2	33040031	Click pawl	920	0920474	Washer
305-1	33050020	Click pawl spring	920	0920475	Washer
305-2	33050022	Click pawl spring	920	0920557	Washer
310	33100034	Drag washer	920	09201002	Washer
315	33150015	Disk break	930	0930086	Screw
324	33240006	Anti-re pawl	930	0930872	Screw
327	33270007	Drag knob bushing	930	0930188	Screw
329	33290008	Compression spring	930	09301170	Screw
333	33330003	Compression spring	930	09301178	Screw
340	33400008	Drag washer retainer	940	0940006	O ring
341	33410001	Drag washer bushing	940	0940029	O ring
343	33430001	Anti-re pawl bushing	940	0940048	O ring

309OKM04002121