



RTX-80 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004155	MAIN BODY	705	27050149	TRANSMISSION GEAR
105	0910332	PINION BEARING FIXED PLATE	708	27080128	OSCILLATING SLIDER
105-1	0910396	BALL BEARING PLATE	716	27160010	OSCILLATION SLIDER PLATE
108	21087085	CAP	718	27180773	MAIN SHAFT
200	22004392	SIDE PLATE	719	27190005	CLICK GEAR
201	22010600	MAIN BODY DECORATION	722	27220005	CLICK GEAR WASHER
201-1	22010601	SIDE PLATE DECORATION	722-1	27220036	CLICK GEAR WASHER
201-2	22010602	MAIN BODY DECORATION	725	27250019	TRANSMISSION GEAR BUSHING
201-3	22010603	SIDE PLATE DECORATION	725-1	27250002	TRANSMISSION GEAR BUSHING
300	23004938	ROTOR	800	28000255	ANTI-REVERSE/ANTI-RE LEVER
301	23012023	BAIL ARM	800-1	28000327	ANTI-REVERSE/ANTI-RE LEVER
304	23042695	BAIL ARM COVER	801	28010039	ANTI-RE LEVER SPRING
305	23050182	KICK LEVER	0910494	0910494	BALL BEARING
307	23071729	BAIL HOLDER	0910184	0910184	BALL BEARING
309	23090037	BAIL ARM SUPPORT PIN	0910141	0910141	BALL BEARING
310	23100070	COMPRESSION SPRING	0910015	0910015	BALL BEARING
313	23131679	BAIL WIRE ASSY.	0910018	0910018	BALL BEARING
315	23150010	LINE ROLLER	0920539	0920539	WASHER
317	23170008	LINE ROLLER WASHER	0920209	0920209	WASHER
318	23180008	ROTOR NUT	0920169	0920169	WASHER
400	240014888	SPOOL ASSY	0920168	0920168	WASHER
405	24050031	DRAG WASHER RETAINER	0930452	0930452	SCREW
407	24070006	EXTENSION SPRING	0930575	0930575	SCREW
412-1	24120019	SPOOL BUSHING	0930562	0930562	SCREW
413	24130014	WATERPROOF RETAINER	0930945	0930945	SCREW
500	25005891	HANDLE ASSY.	09301388	09301388	SCREW
504	25040003	HANDLE SCREW CAP WASHER	0930058	0930058	SCREW
513	25130832	HANDLE CAP	09301391	09301391	SCREW
600	26003698	DRAG KNOB ASSY.	0930473	0930473	SCREW
610	26100053	DRAG WASHER	09301389	09301389	SCREW
611	26110021	EARED WASHER	0930643	0930643	SCREW
612	26120063	KEY WASHER	09301380	09301380	SCREW
612-2	26120064	KEY WASHER	09301390	09301390	SCREW
700	27002027	DRIVE GEAR	0930663	0930663	SCREW
702	27020343	PINION GEAR			

209OKA09305801