



RTX-25 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004166	Main body	702	27020759	Pinion gear
105	21050012	Pinion bearing fixed plate	705	27050158	Transmission gear
105-1	21056571	Pinion bearing fixed plate	708	27080167	Oscillating slider
108	21081458	Cap	716	27160008	Oscillation slider plate
200	22004321	Side plate	718	27180746	Main shaft
201	22010481	Main body decoration	719	27190025	Click gear
201-1	22010482	Side plate decoration	722	27220009	Click gear washer
201-2	22010483	Main body decoration	800	28000332	Anti-reverse/anti-re lever
201-3	22010484	Side plate decoration	800-1	28000324	Anti-re lever spring
300	23004952	Rotor	801	28010024	Anti-re lever spring
301	23012230	Bail arm	0910525	0910525	Ball bearing
304	23042612	Bail arm cover	0910041	0910041	Ball bearing
305	23050177	Kick lever	0910051	0910051	Ball bearing
307	23071544	Bail holder	0910093	0910093	Ball bearing
309	23090002	Bail arm slider	0910221	0910221	Ball bearing
310	23100005	Compression spring	0910335	0910335	Ball bearing
313	23131571	Bail wire assy.	0920590	0920590	Washer
315	23150086	Line roller	0920322	0920322	Washer
316	23160014	Line roller bushing	0920376	0920376	Washer
317	23170014	Line roller washer	0920154	0920154	Washer
318	23180005	Rotor nut	0920237	0920237	Washer
400	240014426	Spool assy.	0930438	0930438	Screw
405	24050042	Drag washer retainer	0930541	0930541	Screw
407	24070009	Extension spring	09301462	09301462	Screw
412	24120038	Spool bushing	0930209	0930209	Screw
413	24130009	Waterproof retainer	09301376	09301376	Screw
500	25005485	Handle assy.	0930433	0930433	Screw
504	25040004	Handle screw cap washer	0930471	0930471	Screw
513	25130830	Handle cap	09301375	09301375	Screw
600	26003199	Drag knob assy.	09301459	09301459	Screw
610	26100011	Drag washer	0930307	0930307	Screw
611	26110005	Eared washer	09301378	09301378	Screw
612	26120007	Key washer	09301374	09301374	Screw
612-3	26120032	Key washer	0930663	0930663	Screw
700	27002022	Drive gear			