



## RTX-55 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004154	Main body	700	27002024	Drive gear
105	0910332	Pinion bearing fixed plate	702	27020854	Pinion gear
105	0910395	Ball bearing plate	705	27050148	Transmission gear
108	21087084	Cap	708	27080169	Oscillating slider
200	22004391	Side plate	716	27160009	Oscillation slider plate
201	22010596	Main body decoration	718	27180771	Main shaft
201	22010597	Side plate decoration	719	27190025	Click gear
201	22010598	Main body decoration	722	27220009	Click gear washer
201	22010599	Side plate decoration	725	27250002	Transmission gear bushing
300	23004936	Rotor	725	27250020	Transmission gear bushing
301	23012023	Bail arm	725	27250031	Transmission gear bushing
304	23042694	Bail arm cover	800	28000255	Anti-reverse/anti-re lever
305	23050181	Kick lever	800	28000330	Anti-reverse/anti-re lever
307	23071731	Bail holder	801	28010039	Anti-re lever spring
309	23090037	Bail arm support pin	0910487	0910487	Ball bearing
310	23100070	Compression spring	0910015	0910015	Ball bearing
313	23131672	Bail wire assy.	0910281	0910281	Ball bearing
315	23150022	Line roller	0910093	0910093	Ball bearing
317	23170008	Line roller washer	0910335	0910335	Ball bearing
318	23180001	Rotor nut	0910018	0910018	Ball bearing
400	240014885	Spool assy	0920545	0920545	Washer
405	24050031	Drag washer retainer	0920150	0920150	Washer
407	24070006	Extension spring	0930044	0930044	Screw
412	24120022	Spool bushing	0930575	0930575	Screw
413	24130013	Waterproof retainer	0930562	0930562	Screw
500	25005890	Handle assy.	0930945	0930945	Screw
504	25040004	Handle screw cap washer	09301377	09301377	Screw
513	25130830	Handle cap	0930058	0930058	Screw
600	26003199	Drag knob assy.	0930473	0930473	Screw
610	26100053	Drag washer	09301389	09301389	Screw
611	26110021	Eared washer	0930643	0930643	Screw
612	26120049	Key washer	09301380	09301380	Screw
612	26120056	Key washer	09301390	09301390	Screw
612	26120050	Key washer	0930639	0930639	Screw

209OKA09305551