



SLV-4/5 PARTS LIST

KEY NO	PARTS NO	PARTS NAME
100	31000635	Frame
101	31010046	Main shaft
102	31020018	Reel foot
207	32070003	Handle knob spacer
300	33000108	Drag knob assy.
304	33040033	Click pawl assy.
310	33100023	Felt drag washer
310-1	33100035	Cork drag washer
310-2	33100026	Steel drag washer
312	33120006	Glaze Key washer
400	34000686	Spool assy.
400-1	34000552	Spool
404	34040023	Handle knob
405	34050013	Handle knob rivet
408	34080014	Spool reatiner
409	34090001	Spool reatiner spring
410	34100052	Spool cover assy.
413	34130004	Counter balance
900	19000004	E type retainer
901	19010012	C type retainer
910	0910090	One way bearing assy.
920	0920154	Washer
930	0930075	Screw
930	0930081	Screw
930	0930084	Screw
930	0930117	Screw
930	0930920	Screw

309OKM02901041