



SPa-50 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003597	Main body	612-1	26120056	Key washer
105	0910332	Pinion bearing fixed plate	612-2	26120050	Key washer
105-1	21056581	Ball bearing plate	700	27000328	Drive gear
108	21081462	Cap	702	27020853	Pinion gear
200	22003514	Side plate	705	27050100	Transmission gear
201	22010049	Side plate decoration	708	27080097	Oscillating slider
201-1	22010050	Main body decoration	716	27160009	Oscillation slider plate
201-2	22010021	Side plate decoration	718	27180701	Main shaft
201-3	22010023	Main body decoration	719	27190025	Click gear
300	23003900	Rotor	722	27220009	Click gear washer
301	23011799	Bail arm cover	725	27250020	Transmission gear bushing
304	23042617	Bail arm cover	800	28000256	Anti-reverse/anti-re lever
305	23050145	Kick lever	800-1	28000330	Anti-reverse/anti-re lever
306	23061002	Bail holder cover	801	28010039	Anti-reverse spring
307	23073140	Bail holder	0910402	0910402	Ball bearing
309	23090030	Bail arm support pin	0910091	0910091	Ball bearing
310	23100069	Compression spring	0910530	0910530	Ball bearing
313	23131376	Bail wire assy.	0920150	0920150	Washer
315	23150022	Line roller	0920151	0920151	Washer
316	23160002	Line roller bushing	0920545	0920545	Washer
318	23180001	Rotor nut	0930044	0930044	Screw
400	240011566	Spool assy.	0930575	0930575	Screw
405	24050031	Drag washer retainer	0930171	0930171	Screw
407	24070005	Extension spring	0930945	0930945	Screw
500	25005182	Handle assy.	0930471	0930471	Screw
504	25040004	Handle screw cap washer	0930544	0930544	Screw
513	25130830	Handle cap	09301272	09301272	Screw
600	26003399	Drag knob assy.	0930643	0930643	Screw
610	26100053	Drag washer	0930763	0930763	Screw
611	26110021	Eared washer	0930819	0930819	Screw
612	26120049	Key washer	0930623	0930623	Screw

209OKA09001502