



## SS-50B PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21002523	Main body	612	26120056	Key washer
105	21050007	Pinion bearing fixed bushing	612	26120050	Key washer
105	21050022	Pinion bearing fixed bushing	700	27000078	Drive gear
106	21060488	Drag knob seat	702	27020026	Pinion gear
200	22002411	Side plate	705	27050031	Transmission gear
300	23004866	Rotor	708	27080041	Oscillating slider
301	23011947	Bail arm	718	27180397	Main shaft
304	23042626	Bail arm cover	719	27190017	Click gear
305	23050054	Kick lever	722	27220020	Click gear washer
306	23061007	Bail holder cover	722	27220035	Click gear washer
307	23071551	Bail holder	725	27250020	Transmission gear bushing
309	23090029	Bail arm slider	800	28000217	Anti-reverse/anti-re lever
309	23090018	Bail arm support pin	801	28010006	Anti-re lever spring
310	23100047	Compression spring	0910124	0910124	Ball bearing
313	23131605	Bail wire assy.	0910099	0910099	Ball bearing
315	23150022	Line roller	0910093	0910093	Ball bearing
317	23170010	Line rollerwasher	0910015	0910015	Ball bearing
318	23180001	Rotor nut	0910335	0910335	Ball bearing
325	23250005	Bail screw	0910125	0910125	One-way bearing retainer
400	240014460	Spool assy.	0920151	0920151	Washer
405	24050031	Drag washer retainer	0930044	0930044	Screw
407	24070004	Extension spring	0930562	0930562	Screw
413	24130003	Waterproof retainer	0930405	0930405	Screw
500	25005727	Handle assy.	0930471	0930471	Screw
504	25040004	Handle screw cap washer	0930758	0930758	Screw
513	25130833	Handle cap	09301271	09301271	Screw
600	26003224	Drag knob assy.	0930643	0930643	Screw
610	26100053	Drag washer	0930301	0930301	Screw
611	26110021	Eared washer	0930663	0930663	Screw
612	26120049	Key washer			

209CAB04107501