



SS-30B PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21002498	Main body	700	27000061	Drive gear
105	21050005	Pinion bearing fixed plate	702	27020059	Pinion gear
105-1	21050019	Pinion bearing fixed bushing	705	27050029	Transmission gear
106	21060488	Drag knob seat	708	27080043	Oscillating slider
200	22002380	Side plate	718	27180240	Main shaft
300	23004864	Rotor	719	27190008	Click gear
301	23011946	Bail arm	722	27220016	Click gear washer
304	23042624	Bail arm cover	725	27250020	Transmission gear bushing
305	23050052	Kick lever	800	28000209	Anti-reverse/anti-re lever
306	23061005	Bail holder cover	801	28010014	Anti-reverse lever spring
307	23071550	Bail holder	0910070	0910070	Ball bearing
309	23090007	Bail arm slider	0910335	0910335	Ball bearing
309-1	23090055	Bail arm support pin	0910041	0910041	Ball bearing
310	23100087	Compression spring	0910051	0910051	Ball bearing
313	23131604	Bail wire assy.	0910093	0910093	Ball bearing
315	23150010	Line roller	0910015	0910015	Ball bearing
317	23170010	Line rollerwasher	0910071	0910071	One-way bearing retainer
318	23180005	Rotor nut	0920310	0920310	Washer
325	23250002	Bail screw	0920376	0920376	Washer
400	240014458	Spool assy.	0920151	0920151	Washer
405	24050031	Drag washer retainer	0930044	0930044	Screw
407	24070009	Extension spring	0930171	0930171	Screw
413	24130003	Waterproof retainer	0930405	0930405	Screw
500	25006244	Handle assy.	0930471	0930471	Screw
504	25040004	Handle screw cap washer	0930758	0930758	Screw
513	25130833	Handle cap	09301265	09301265	Screw
600	26003224	Drag knob assy.	0930643	0930643	Screw
610	26100049	Drag washer	0930301	0930301	Screw
611	26110018	Eared washer	0930663	0930663	Screw
612	26120059	Key washer			

209CAB04107301