



SS-80B PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21002757	Main body	611	26110021	Eared washer
105	0910332	Pinion bearing fixed plate	612	26120063	Key washer
105	0910396	Ball bearing plate	612	26120064	Key washer
106	21060489	Drag knob seat	700	27000104	Drive gear
200	22002532	Side plate	702	27020901	Pinion gear
300	23004868	Rotor	705	27050035	Transmission gear
301	23011947	Bail arm	708	27080026	Oscillating slider
304	23042628	Bail arm cover	718	27180186	Main shaft
305	23050049	Kick lever	719	27190005	Click gear
306	23061009	Bail holder cover	722	27220014	Click gear washer
307	23071552	Bail holder	722	27220036	Click gear washer
309	23090029	Bail arm slider	725	27250019	Transmission gear bushing
309	23090018	Bail arm support pin	800	28003461	Anti-reverse/anti-re lever
310	23100025	Compression spring	801	28010006	Anti-re lever spring
313	23131607	Bail wire assy.	0910419	0910419	Ball bearing
315	23150022	Line roller	0910184	0910184	Ball bearing
317	23170010	Line rollerwasher	0910141	0910141	Ball bearing
318	23180003	Rotor nut	0910015	0910015	Ball bearing
325	23250005	Bail screw	0920169	0920169	Washer
400	240014462	Spool assy.	0930452	0930452	Screw
405	24050031	Drag washer retainer	0930564	0930564	Screw
407	24070026	Extension spring	0930080	0930080	Screw
413	24130004	Waterproof retainer	0930458	0930458	Screw
500	25005728	Handle assy.	0930758	0930758	Screw
504	25040003	Handle screw cap washer	09301271	09301271	Screw
513	25130834	Handle cap	0930643	0930643	Screw
600	26003226	Drag knob assy.	0930301	0930301	Screw
610	26100053	Drag washer	0930678	0930678	Screw

209CAB04107801