



SR - 20L Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000938	11100027111	MAIN BODY ASSY		701	17010070	1170100913001A	DRIVE GEAR SHAFT	
105	11050006	11105003-01	WORM SHAFT BUSHING		702	17020310	1170203603002	PINION GEAR	
105-1	11050007	11105004-01	WORM SHAFT BUSHING		703	17030008	11703009-03	WORM SHAFT GUARD	
117	11170012	11117007-03001	NUT		704	17040012	11704008-03	LINE GUIDE SUPPORT BAR	
200	12001010		MAIN SIDE PLATE		705	17050011	11705006-06	TRANSMISSION GEAR	
201	12010011	11201008-06	ANTI-RE PAWL		706	17060003	11706002-06	TRANSMISSION GEAR	
207	12070052	11207017-03001	HOLDED PLATE		707	17070009	11707008-11	TRANSMISSION GEAR	
208	12080045		SIDE PLATE COVERS		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
211	12110009	11211003-03001	ANTI-RE PAWL PIN		710	17100040	1171000906	LINE GUIDE ASSY.	
215	12150015	11215011-03001	HOLD PLATE BUSHING		712	17120026	11712019-03	WORM SHAFT	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
216-1	12160003	11216002-06	ANTI-RE PAWL SPRING		715	17150004	11715003-06001	LINE GUIDE PAWL	
221	12210001	11221001-07	"O"RING		800	18000012	11800004-02002	CLUTCH CAM	3031
300	13000444	11300030-01001	SIDE PLATE		800	18000014	11800004-12002	CLUTCH CAM	
302	13020014	11302002-06001	WASHER		801	18010006		CLUTCH SPRING	
302-1	13020005	11302005-03	BUSHING		802	18020001	11802003-01	CLUTCH BAR	
302-3	13020017	11302006-03	WASHER	3024	804	18040005	11804005-06	CLUTCH CAM SLIDER	
303	13030045	11303010-03907	CLICK BUTTON		805	18050002	11805002-01	PINION GEAR YOKE	
304	13040001	11304003-06	CLICK PAWL		806	18060001	11806001-06	YOKE SPRING	
305	13050007	11305001-01003	CLICK PAWL SPRING		9201	0920283	025.1x8x0.5-6	WASHER	
311	13110028	11311007-06001	SIDE PLATE COVERS		9201-1	0920162	028x10x0.5-6	WASHER	
400	14000309	11400029-01001C	SPOOL		9202	0920114	025.1x9.5x0.2-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9205	0920327	028.1x18x1-1	WASHER	3036
500	15000173	1150001304907A	HANDLE ASSY.		9205	0920339	028x15x1-1	WASHER	
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9206	0920085	024.05x10x0.2-8	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9207	0920066	022x4.9x0.2-3	WASHER	
600	16000038	11600014-03001	CAST CONTROL CAP		9209	0920282	025.1x8x0.2-6	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER		9301	0930550	03222.6x12-64	SCREW	
609	46090003	14609003-06001	WASHER	3013	9302	0930219	03327.52.6x6-61	SCREW	
610	16100017	11610004-000	DRAG WASHER		9302-1	0930298	03422.6x13-61	SCREW	
610-1	16100030	11610013-000	DRAG WASHER		9307	0930696	03412.6x4-64	SCREW	
611	16110005	11611005-06	EARED WASHER		9312	0930210	03325.2x2x4.561	SCREW	
612	16120027	11612007-06001	KEY WASHER		9314	0930575	03222x4.5-61	SCREW	
614	16140001	11614001-06	SPRING WASHER		9316	0930734	03414x5-647	SCREW	
615	16150016		STAR DARG KNOB		9317	0930194	03312x3.5-61	SCREW	
617	16170008	11617006-01002	DRIVE GEAR SHAFT BUSHING		9319	0930196	03312x5-61	SCREW	
617-1	16170018	11617015-03	DRIVE GEAR SHAFT BUSHING		9321	0930202	03319.4x3x7-61	SCREW	
700	17000205	1170000803003	DRIVE GEAR		9404	29000001	12900001-06	E RETAINER	