



SR - 30L Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11001211	1110008901001	MAIN BODY ASSY.		703	17030006	11703007-03907	WORM SHAFT GUARD	
105	11050006	11105003-01	WORM SHAFT BUSHING		704	17040008	11704005-03907	WORM GUIDE SUPPORT BAR	
117	11170012	11117007-03001	NUT		705	17050013	11705008-06	TRANSMISSION GEAR	
200	12001026		MAIN SIDE PLATE		706	17060006	11706003-06	TRANSMISSION GEAR	
201	12010001	11201001-06	ANTI-REVERSE PAWL		707	17070004	11707003-01	TRANSMISSION GEAR	
207	12070046	11207011-03001	HOLDED PLATE		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
208	12080035		SIDE PLATE COVERS		710	17100009	1171000506	LINE GUIDE ASSY	
211	12110006	11211005-03001	ANTI-RE PAWL PIN		712	17120019	11712010-03907	WORM SHAFT	
215	12150015	11215011-03001	HOLD PLATE BUSHING		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		715	17150004	11715003-06001	LINE GUIDE PAWL	
221	12210001	11221001-07	"O"RING		800	18000012	11800004-02002	CLUTCH CAM	3031
300	13000139	11300025-11	SIDE PLATE		800	18000014	11800004-12002	CLUTCH CAM	
302	13020014	11302002-06001	WASHER		801	18010007	11801005-06001	CLUTCH SPRING	
302-1	13020005	11302005-03	BUSHING		802	18020001	11802003-01	CLUTCH BAR	
303	13030005	11303004-03907	CLICK BUTTON		804	18040001	11804001-06	CLUTCH CAM SLIDER	
304	13040001	11304003-06	CLICK PAWL		805	18050001	11805001-06	PINION GEAR YOKE	
305	13050007	11305001-01003	CLICK PAWL SPRING		806	18060001	11806001-06	YOKE SPRING	
311	13110020	11311004-06001	SIDE PLATE COVERS		9201	0920283	025.1x8x0.5-6	WASHER	
400	14000283	11400010-0112	SPOOL		9201-1	0920157	028.1x12x0.8-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9202	0920114	025.1x9.5x0.2-6	WASHER	
500	15000159	1150001004907	BALANCE HANDLE ASSY.		9205	0920327	028.1x18x1-1	WASHER	3036
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9205	0920339	028x15x1-1	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9206	0920085	024.05x10x0.2-8	WASHER	
600	16000038	11600014-03001	CAST CONTROL CAP		9207	0920066	022x4.9x0.2-3	WASHER	
609	16090002	11609003-05907	DRAG SPRING WASHER	3008	9209	0920282	025.1x8x0.2-6	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER		9210	0920108	025.1x10.5x5-6	WASHER	
610	16100017	11610004-000	DRAG WASHER		9301	0930586	03223x11.5-64	SCREW	
610-1	16100030	11610013-000	DRAG WASHER		9302	0930219	03327.52.6x6-61	SCREW	
611	16110005	11611005-06	EARED WASHER		9307	0930696	03412.6x4-64	SCREW	
612	16120027	11612007-06001	KEY WASHER		9311	0930589	03223x12-64	SCREW	
614	16140001	11614001-06	SPRING WASHER		9312	0930651	03327.52.67.561	SCREW	
615	16150030		STAR DARG KNOB		9314	0930575	03222x4.5-61	SCREW	
617	16170008	11617006-01002	DRIVE GEAR SHAFT BUSHING		9316	0930734	03414x5-647	SCREW	
617-1	16170018	11617015-03	DRIVE GEAR SHAFT BUSHING		9317	0930194	03312x3.5-61	SCREW	
700	17000026	11700006-032	DRIVE GEAR		9319	0930196	03312x5-61	SCREW	
701	17010077		DRIVE GEAR SHAFT		9321	0930202	03319.4x3x7-61	SCREW	
702	17020237	11702037-06001	PINION GEAR	3107	9404	29000001	12900001-06	E RETAINER	
702	17020322	0	PINION GEAR		9504	19010001	11901001-06	C RETAINER	