



Sierra 4/5 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	31000202	Body assy. (with main shaft)	405	34050008	Handle knob rivet
102	31020008	Reel foot	408	34080014	Spool reatiner
111	31110004	Click pawl	409	34090001	Spool reatiner spring
300	33000019	Drag knob	410	34100018	Spool cover assy.
303	33030006	Holder plate	413	34130003	Counter balance
304	33040014	Click pawl	416	34160003	Bearing bushing
305	33050018	Click pawl spring	420	34200001	Handle knob pad
314	33140001	Spring washer	509	35090001	E type reatiner
315	33150002	Disk break	901	29010004	Fixed washer
332	33320006	Break block	910	0910086	One way bearing
332-1	33320007	Break block	920	0920056	Washer
333	33330002	Compression spring	920	0920077	Washer
335	33350001	Clutch plate	930	0930075	Screw
336	33360002	Nut	930	0930081	Screw
400	34000120	Spool assy.	930	0930084	Screw
400-1	34000703	Spool	930	0930117	Screw
403	34030005	Click gear	930	09301219	Screw
404	34040030	Handle knob			

309OKM02402041