



SLX-20L PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001974	Main body	704	17040035	Worm guide support bar
101	11010033	Body load	705	17050020	Transmission gear
102	11020103	Body foot	707	17070010	Transmission gear
103	11030003	Screw	708	17080007	Transmission gear
104	11040001	Body foot nut	709	17090014	Transmission gear bushing
105	11050018	Worm shaft bushing	709-1	17090025	Transmission gear bushing
105-1	11050009	Worm shaft bushing	710	17100098	Line guide assy
108	11080019	Hanger	712	17120059	Worm shaft
108-1	11080017	Hanger	713	17130002	Line guide pawl cap
108-2	11080030	The protection cover of reels lugs	715	17150001	Line guide pawl
114	11140005	Clamp	717	17170004	Main shaft pin
115	11150006	Wing screw	718	17180368	Main shaft
116	11160003	Reel clamp nuts	723	17230009	Silent spring
117	11170002	Retainer nut	913	19130002	Spring washer
200	12002095	Handle side plate	19000001	19000001	E retainer
201	12010027	Anti-re pawl	19000004	19000004	E retainer
203	12030004	Control pin	19010006	19010006	C retainer
204	12040002	Compression spring	29000001	29000001	E retainer
205	12050033	Decoration plate	0910179	0910179	Ball bearing
206	12060016	Stopper cap	0910586	0910586	Thrust bearing assy
207	12070076	Holded plate	0910599	0910599	Thrust bearing assy
208	12080106	Side plate cover	0910103	0910103	Ball bearing
215	12150022	Hold plate bushing	0910592	0910592	Ball bearing
215-1	12150023	Hold plate bushing	0910591	0910591	Ball bearing
217	12170014	Anti-re pawl spring	0920004	0920004	Washer
217-1	12170018	Anti-re pawl spring	0920068	0920068	Washer
300	13001126	Vice side plate	09201000	09201000	Washer
303	13030012	Click button	0920207	0920207	Washer
304	13040019	Click pawl	0920209	0920209	Washer
305	13050014	Click pawl spring	0920218	0920218	Washer
311	13110099	Side plate covers	0920319	0920319	Washer
400	14001072	Spool	0920426	0920426	Washer
401	14010036	Click gear	0920453	0920453	Washer
405	14050031	Spool cover	0920480	0920480	Washer
406	14060006	Bushing	0920490	0920490	Washer
500	15000457	Handle assy.	0920503	0920503	Washer
501	15010013	Handle nut	0920506	0920506	Washer
507	15070032	Push button	0920510	0920510	Washer
513	15130025	Handle cover	0920481	0920481	Washer
516	15160030	Handle nut retainer	0920263	0920263	Washer
600	16000101	Cast control cap	0920152	0920152	Washer
601	16010004	Compression spring	0930044	0930044	Screw
602	16020049	Adjust block	0930048	0930048	Screw
605	16050207	Lever drag assy.	09301052	09301052	Screw
607	16070093	Pinion guard	09301115	09301115	Screw
608	16080004	Drag washer retainer	0930129	0930129	Screw
609	16090012	Spring washer	0930196	0930196	Screw
611	16110050	Drag washer	0930211	0930211	Screw
612	16120064	Key washer	0930614	0930614	Screw
612-1	16120102	Key washer	0930646	0930646	Screw
613	16130007	Compression spring	0930668	0930668	Screw
700	17000403	Drive gear	09301130	09301130	Screw
701	17010309	Drive gear shaft	0930651	0930651	Screw
702	17020505	Pinion gear	09301256	09301256	Screw
703	17030019	Worm shaft guard	0940056	0940056	O ring