



SD - 45D Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000864	11100016011	MAIN BODY ASSY		707	17070004	11707003-01	TRANSMISSION GEAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		708	17080003	11708003-11	TRANSMISSION GEAR	
117	11170012	11117007-03001	NUT		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
200	12000747	11200040-01001C	HANDLE SIDE PLATE		710	17100046	1171001306917	LINE GUIDE ASSY.	
201	12010001	11201001-06	ANTI-RE PAWL		712	17120031	11712022-03907	WORM SHAFT	
207	12070044	11207003-06001	HOLDED PLATE		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
211	12110008	11211002-03001	ANTI-RE PAWL PIN		715	17150004	11715003-06001	LINE GUIDE PAWL	
212	12120009	1121200101	COUNTER COVER		800	18000005	11800002-02002	CLUTCH CAM	3031
215	12150015	11215011-03001	HOLD PLATE BUSHING		800	18000008	11800002-12002	CLUTCH CAM	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		801	18010001	11801001-06	CLUTCH SPRING	
221	12210001	11221001-07	"O"RING		802	18020054	11802006-01	CLUTCH BAR	
300	13000150	11300026-01	VICE SIDE PLATE		804	18040001	11804001-06	CLUTCH SLIDER	
302	13020014	11302002-06001	WASHER		805	18050001	11805001-06	PINION GEAR YOKE	
303	13030005	11303004-03907	CLICK BUTTON		806	18060001	11806001-06	YOKE SPRING	
304	13040001	11304003-06	CLICK PAWL		910	19100007	11910002-01003	DEPTH COUNTER	
305	13050007	11305001-01003	CLICK PAWL SPRING		9101	0910321	01030625-61	BALL BEARING	
311	13110024	11311005-06002	SIDE PLATE COVER		9102	0910099	01081605-61	BALL BEARING	
400	14000441	1140003404007B	SPOOL		9106	0910227	01041104-61	BALL BEARING	
401	14010026	1140101101	CLICK GEAR		9201	0920283	025.1x8x0.5-6	WASHER	
500	15000119	1150000604004A	HANDLE ASSY.		9201-1	0920157	028.1x12x0.8-6	WASHER	
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9202	0920114	025.1x9.5x0.2-6	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9205	0920339	028x15x1-1	WASHER	
600	16000042	11600014-03003	CAST CONTROL CAP		9206	0920085	024.05x10x0.2-8	WASHER	
608	16080006	11608004-06	RETAINER		9207	0920066	022x4.9x0.2-3	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER		9209	0920282	025.1x8x0.2-6	WASHER	
610	16100018	11610004-006A	DRAG WASHER		9210	0920108	025.1x10.5x5-6	WASHER	
610-1	16100032	11610013-000	DRAG WASHER		9301	0930802	03423x13-61	SCREW	
611	16110005	11611005-06	EARED WASHER		9302	0930219	03327.52.6x6-61	SCREW	
612	16120027	11612007-06001	KEY WASHER		9307	0930226	03412.6x4-61	SCREW	
612-1	16120029	11612007-06003	KEY WASHER		9311	0930588	03223x12-61	SCREW	
614	16140001	11614001-06	WASHER		9311-1	0930448	03123x10-61	SCREW	
615	16150021	11615005-01001	STAR DARG KNOB		9312	0930651	03327.52.67.561	SCREW	
617	16170002	11617005-03	DRIVE GEAR SHAFT BUSHING		9314	0930575	03222x4.5-61	SCREW	
700	17000199	1170000603002	DRIVE GEAR		9316	0930732	03414x5-617	SCREW	
701	17010073	1170101603001A	DRIVE GEAR SHAFT		9320	0930426	03122x26-61	SCREW	
702	17020237	11702037-06001	PINION GEAR		9320-1	0930062	03122x8-62	SCREW	
703	17030005	11703006-03907	WORM SHAFT GUARD		9321	0930618	03319.4x3x7-611	SCREW	
704	17040007	11704004-03907	LINE GUIDE SUPPORT BAR		9404	29000001	12900001-06	E RETAINER	
705	17050013	11705008-06	TRANSMISSION GEAR		9404-1	19000002	11900002-06	E RETAINER	
706	17060006	11706003-06	TRANSMISSION GEAR		9504	19010001	11901001-06	C RETAINER	