



SD - 55L Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11001135	1110005701001	MAIN BODY ASSY.		707	17070010	11707009-06001	TRANSMISSION GEAR	
105	11050009	11105006-01	WORM SHAFT BUSHING		708	17080007	11708007-06001	TRANSMISSION GEAR	
107	11070021	11107018-06001	LINE GUARD		709	17090014	11709006-03001	TRANSMISSION GEAR BUSHING	
108	11080014	11108010-06001	HANGER		709-1	17090015	11709007-03001	TRANSMISSION GEAR BUSHING	
117	11170014	11117005-06001	NUT		710	17100019	1171001106917	LINE GUIDE ASSY.	
200	12000783	11200050-01001C	MAIN SIDE PLATE		712	17120035	11712026-03001	WORM SHAFT	
201	12010018	11201010-06001	ANTI-RE PAWL		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
207	12070056	11207022-06001	HOLDED PLATE		715	17150001	11715002-06	LINE GUIDE PAWL	
208	12080025	11208012-06002	SIDE PLATE COVERS		724	17240001	11724001-06001	CLICK PAWL	
211	12110008	11211002-03001	ANTI-RE PAWL PIN		800	18000012		CLUTCH CAM	3031
215	12150015	11215011-03001	HOLD PLATE BUSHING		800	18000014	11800004-12002	CLUTCH CAM	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		801	18010001	11801001-06	CLUTCH SPRING	
221	12210001	11221001-07	"O"RING		802	18020015	11802004-01	CLUTCH BAR	
300	13000495	11300041-01001	VICE SIDE PLATE		804	18040007	11804007-06001	CLUTCH SLIDER	
302	13020015	11302002-06002	WASHER		805	18050007	0	PINION GEAR YOKE	
303	13030040	11303004-03914	CLICK BUTTON		806	18060002	11806001-061	YOKE SPRING	
304	13040001	11304003-06	CLICK PAWL		9101	0910335	01040725-61	BALL BEARING	
305	13050007	11305001-01003	CLICK PAWL SPRING		9102	0910099	01081605-61	BALL BEARING	
311	13110034	11311009-06002	SIDE PLATE COVER		9106	0910227	01041104-61	BALL BEARING	
312	13120001	11312001-06001	BALL BEARING HOLD PLATE		9201	0920111	025.1x11.5x.5-6	WASHER	
400	14000510	1140004304007	SPOOL		9202	0920279	025.1x10.5x.1-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9204	0920291	025.9x10x0.2-6	WASHER	
500	15000134	1150000604006	HANDLE ASSY.		9205	0920167	028x36x1-1	WASHER	
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9207	0920066	022x4.9x0.2-3	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9209	0920304	026.05x9x0.2-6	WASHER	
600	16000055	11600016-03003	CAST CONTROL CAP		9301	0930589	03223x12-64	SCREW	
608	16080006	11608004-06	DRAG WASHER RETAINER		9301-1	0930400	03122.6x12-64	SCREW	
609	16090002		DRAG SPRING WASHER	3008	9301-2	0930595	03223x20-64	SCREW	
609	16090003	11609003-06001	DRAG SPRING WASHER		9302	0930651	03327.52.67.561	SCREW	
610	16100026	11610010-01001	DRAG WASHER		9302-1	0930176	03222.6x9.5-61	SCREW	
610-1	16100033	11610014-01001	DRAG WASHER		9307	0930697	03412.6x5-64	SCREW	
611	16110040	11611018-06001	EARED WASHER		9307	0930697	03412.6x5-64	SCREW	
612	16120039	11612019-06001	KEY WASHER		9309	0930519	03213x12-61	SCREW	
612-1	16120045	11612026-06001	KEY WASHER		9311	0930589	03223x12-64	SCREW	
614	16140001	11614001-06	DRAG WASHER		9311-1	0930591	03223x16-64	SCREW	
615	16150021	11615005-01001	STAR DARG WRENCH		9313	0930206	03322.6x6-61	SCREW	
617	16170002	11617005-03	DRIVE GEAR SHAFT BUSHING		9316	0930734	03414x5-647	SCREW	
700	17000247	1170002806002	DRIVE GEAR		9317	0930194	03312x3.5-61	SCREW	
701	17010132	1170103016001	DRIVE GEAR SHAFT		9319	0930196	03312x5-61	SCREW	
702	17020266	11702030062	PINION GEAR		9321	0930202	03319.4x3x7-61	SCREW	
703	17030009	11703010-03907	WORM SHAFT GUARD		9325	0930663	033272.6x4.5-61	SCREW	
704	17040028	11704019-03001	LINE GUIDE SUPPORT BAR		9404	29000001	12900001-06	E RETAINER	
705	17050015	11705009-032	TRANSMISSION GEAR		9404-1	29000002	12900002-06	E RETAINER	
705-1	17050017	11705010-06001	TRANSMISSION GEAR						