




SV-10-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004081	Main body	702	27020490	Pinion gear
105	21056605	Pinion bearing fixed bushing	705	27050153	Transmission gear
105-1	21056616	Pinion bearing fixed plate	705-1	27050222	Transmission gear
108	21087129	Cap	708	27080130	Oscillating slider
200	22004327	Side plate	716	27160026	Oscillation slider plate
201	22010379	Main body decoration	718	27180726	Main shaft
201-1	22010380	Side plate decoration	719	27190025	Click gear
201-2	22010739	Main body decoration	722	27220009	Click gear washer
201-3	22010740	Side plate decoration	722-1	27220037	Click gear washer
300	23005039	Rotor	725	27250028	Transmission gear bushing
301	23012076	Bail arm	800	28000332	Anti-reverse/anti-re lever
304	23042766	Bail arm cover	800-1	28000402	Anti-reverse/anti-re lever
305	23050214	Kick lever	801	28010024	Anti-re lever spring
307	23071788	Bail holder	0910618	0910618	Ball bearing
309	23090051	Bail arm support pin	0910015	0910015	Ball bearing
310	23100085	Compression spring	0910051	0910051	Ball bearing
313	23134325	Bail wire assy.	0910041	0910041	Ball bearing
315	23150029	Line roller	0910335	0910335	Ball bearing
317	23170013	Line rollerwasher	0920136	0920136	Washer
317-1	23170024	Line roller washer	0920600	0920600	Washer
318	23180019	Rotor nut	0930541	0930541	Screw
400	240015308	Spool assy.	09301326	09301326	Screw
405	24050042	Drag washer retainer	0930307	0930307	Screw
407	24070009	Extension spring	0930928	0930928	Screw
500	25006226	Handle assy.	0930060	0930060	Screw
513	25130835	Handle cap	0930438	0930438	Screw
515	25150002	Handle screw cap washer	09301327	09301327	Screw
600	26003232	Drag knob assy.	09301265	09301265	Screw
610	26100011	Drag washer	09301450	09301450	Screw
612	26120006	Key washer	0930429	0930429	Screw
612-1	26120054	Key washer	0930830	0930830	Screw
700	27000445	Drive gear			

209OKA09018101