



SV-266LX PARTS LIST

Key no	Part name	PART NUMBER SV-266LX	Key no	Part name	PART NUMBER SV-266LX	Key no	Part name	PART NUMBER SV-266LX
1	Palm Side Cover Assembly	5K276115	27	Thumb Bar Assembly	5K138303	53	Washer-L	5k039901
2	Lock Pin	5K134801	28	Kick Lever Spring	5K138201	54	Washer-D	5K040001
3	Coil Spring	6K974401	29	Kick Lever	5K137301	55	One Way Clutch Assembly	6K859301
4	Magnet Holder Assembly	5K102301	30	Clutch Cam Spring	5K138401	56	Bush	6K859205
5	Tap Screw	5K047001	31	Clutch Cam	5K137201	57	Ball Bearing	6K582201
6	Washer	5K027001	32	Screw	6k787601	58	Washer	6K177302
7	Ball Bearing	6k474502	33	Screw	6k787601	59	Leaf Spring Assembly	6K259201
8	Ring	6k468301	34	Clutch	5K133401	60	Spring Washer	5K027201
9	Spool Assembly(1Ball Bearing)	5k279811	35	Coil Spring	6K942501	61	Washer	6k193601
10	Screw	6K311311	36	Pinion	5K153801	62	Star Drag	5K1339E1
11	Screw	6K311306	37	Gear Side Cover Assembly	5K276014	63	Leaf Spring	6K161404
12	Screw	6K395604	38	O-Ring	6K176501	64	Handle Assembly(2 Ball Bearing)	5K135325
13	Retainer	6B339801	39	Bearing	6K176801	65	Handle Nut	5K047106
14	Bush	6K456801	40	Washer	5K027001	66	Retainer	5K155102
15	Level Wind Assembly	6k931104	41	Washer	6K181101	67	Screw	63508912
16	Level Wind Pin	6K256501	42	Tension Nut	6K181202	68	Control Dial	5K132401
17	Washer	6K148801	43	Screw	6K311306	69	Leaf Spring	6K974701
18	Level Wind Nut	6K704403	44	Ball Bearing	6K170602	70	O-Ring	6K180201
19	Pipe	6K456403	45	Retainer	63201402	71	Slide Cam-B	5K137901
20	Worm Shaft	5K095605	46	Bearing Plate	5K134901	72	Coil Spring	5K100501
21	Washer	6E096503	47	Screw	63535902	73	Slide Cam-A	5K284701
22	Worm Pinion	6K469301	48	Gear Metal	5K093604	74	Spool Cover	5K276201
23	Retainer	6B339801	49	Gear	6K258101	75	Screw	6K509702
24	Hood	5K136724	50	Ratchet	6K893602	76	Washer	6E096501
25	Pillar	6K930403	51	Washer	5K027101	77	Bush	6K261702
26	Frame Assembly	5K138917	52	Drive Gear	5K131302			