




SV-35-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003755	Main body	700	27000322	Drive gear
105	21050027	Pinion bearing fixed plate	702	27020903	Pinion gear
105-1	21056578	Pinion bearing fixed bushing	705	27050105	Transmission gear
105-2	21056594	Pinion bearing fixed bushing	708	27080095	Oscillating slider
108	21087116	Cap	716	27160007	Oscillation slider plate
200	22003868	Side plate	718	27180705	Main shaft
201	22010701	Main body decoration	719	27190025	Click gear
201-1	22010702	Side plate decoration	722	27220009	Click gear washer
201-2	22010703	Main body decoration	722-1	27220037	Click gear washer
201-3	22010704	Side plate decoration	725	27250020	Transmission gear bushing
300	23005014	Rotor	800	28000241	Anti-reverse/anti-re lever
301	23012060	Bail arm	800-1	28000322	Anti-reverse/anti-re lever
304	23042743	Bail arm cover	801	28010024	Anti-re lever spring
305	23050207	Kick lever	0910633	0910633	Ball bearing
307	23071770	Bail holder	0910041	0910041	Ball bearing
309	23090051	Bail arm support pin	0910015	0910015	Ball bearing
310	23100079	Compression spring	0910051	0910051	Ball bearing
313	23131694	Bail wire assy.	0910093	0910093	Ball bearing
315	23150029	Line roller	0910335	0910335	Ball bearing
317	23170024	Line roller washer	0920540	0920540	Washer
317-1	23170026	Line rollerwasher	0920376	0920376	Washer
318	23180005	Rotor nut	0920154	0920154	Washer
400	240015212	Spool assy.	0930044	0930044	Screw
405	24050042	Drag washer retainer	0930575	0930575	Screw
407	24070009	Extension spring	0930171	0930171	Screw
500	25006227	Handle assy.	0930209	0930209	Screw
504	25040004	Handle screw cap washer	0930438	0930438	Screw
513	25130788	Handle cap	0930471	0930471	Screw
600	26003034	Drag knob assy.	09301265	09301265	Screw
610	26100011	Drag washer	0930643	0930643	Screw
611	26110005	Eared washer	0930429	0930429	Screw
612	26120007	Key washer	0930838	0930838	Screw
612-1	26120054	Key washer	0930663	0930663	Screw
612-2	26120006	Key washer			

209OKA09318351