



SV-55-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003756	Main body	612-2	26120050	Key washer
105	0910332	Pinion bearing fixed plate	700	27000328	Drive gear
105-1	0910395	Ball bearing plate	702	27020854	Pinion gear
105-2	21056595	Pinion bearing fixed bushing	705	27050100	Transmission gear
108	21087119	Cap	708	27080097	Oscillating slider
200	22003869	Side plate	716	27160009	Oscillation slider plate
201	22010705	Main body decoration	718	27180700	Main shaft
201-1	22010706	Side plate decoration	719	27190025	Click gear
201-2	22010707	Main body decoration	722	27220009	Click gear washer
201-3	22010708	Side plate decoration	725	27250020	Transmission gear bushing
300	23005015	Rotor	800	28000255	Anti-reverse/anti-re lever
301	23012061	Bail arm	800-1	28000330	Anti-reverse/anti-re lever
304	23042744	Bail arm cover	801	28010039	Anti-re lever spring
305	23050210	Kick lever	0910487	0910487	Ball bearing
307	23071771	Bail holder	0910281	0910281	Ball bearing
309	23090037	Bail arm support pin	0910093	0910093	Ball bearing
310	23100066	Compression spring	0910015	0910015	Ball bearing
313	23131696	Bail wire assy.	0910335	0910335	Ball bearing
315	23150010	Line roller	0920545	0920545	Washer
317	23170008	Line roller washer	0920376	0920376	Washer
318	23180001	Rotor nut	0920154	0920154	Washer
400	240015217	Spool assy.	0930044	0930044	Screw
405	24050031	Drag washer retainer	0930575	0930575	Screw
407	24070006	Extension spring	0930171	0930171	Screw
412-1	24120022	Spool bushing	0930945	0930945	Screw
500	25006229	Handle assy.	0930058	0930058	Screw
504	25040004	Handle screw cap washer	0930471	0930471	Screw
513	25130788	Handle cap	09301271	09301271	Screw
600	26003034	Drag knob assy.	0930643	0930643	Screw
610	26100053	Drag washer	0930964	0930964	Screw
611	26110021	Eared washer	0930819	0930819	Screw
612	26120049	Key washer	0930623	0930623	Screw
612-1	26120056	Key washer			

2090KA09318551