




SVI-10-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004239	Main body	705	27050153	Transmission gear
105	21050171	Pinion bearing fixed bushing	705-1	27050222	Transmission gear
105-1	21056616	Pinion bearing fixed bushing	708	27080130	Oscillating slider
108	21081636	Cap	716	27160026	Oscillation slider plate
200	22004477	Side plate	718	27180726	Main shaft
201	22011236	Main body decoration	719	27190025	Click gear
201-1	22011237	Side plate decoration	722	27220009	Click gear washer
300	23005039	Rotor	722-1	27220037	Click gear washer
301	23012393	Bail arm	800	28000332	Anti-reverse/anti-re lever
304	23042766	Bail arm cover	800-1	28000402	Anti-reverse/anti-re lever
305	23050214	Kick lever	801	28010024	Anti-re lever spring
307	23071788	Bail holder	0910618	0910618	One way assy.
309	23090051	Bail arm support pin	0910051	0910051	Ball bearing
310	23100085	Compression spring	0910041	0910041	Ball bearing
313	23134325	Bail wire assy.	0910335	0910335	Ball bearing
315	23150086	Line roller	0920373	0920373	Washer
316	23160014	Line roller bushing	0920136	0920136	Washer
316-1	23160010	Line roller bushing	0920590	0920590	Washer
317	23170014	Line roller washer	0920237	0920237	Washer
318	23180019	Rotor nut	0920600	0920600	Washer
400	240016272	Spool assy.	0930541	0930541	Screw
405	24050042	Drag washer retainer	09301547	09301547	Screw
407	24070047	Extension spring	0930307	0930307	Screw
500	25006759	Handle assy.	0930928	0930928	Screw
504	25040007	Handle screw cap washer	0930060	0930060	Screw
513	25130868	Handle cap	0930438	0930438	Screw
600	26003232	Drag knob assy.	09301327	09301327	Screw
610	26100011	Drag washer	09301518	09301518	Screw
612	26120006	Key washer	09301450	09301450	Screw
612-1	26120054	Key washer	0930429	0930429	Screw
700	27000445	Drive gear	0930830	0930830	Screw
702	27020490	Pinion gear			

209OKA09040101