




SVI-30-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21009356	Main body	705	27050099	Transmission gear
105	21050012	Pinion bearing fixed plate	708	27080096	Oscillating slider
105-1	21056571	Pinion bearing fixed plate	716	27160008	Oscillation slider plate
105-2	21050139	Pinion bearing fixed bushing	718	27180703	Main shaft
108	21081594	Cap	719	27190025	Click gear
200	22004685	Side plate	722	27220009	Click gear washer
201	22011168	Side plate decoration	800	28000332	Anti-reverse/anti-re lever
201-1	22011167	Main body decoration	800-1	28000324	Anti-reverse/anti-re lever
300	23005013	Rotor	801	28010024	Anti-re lever spring
301	23012360	Bail arm	0910648	0910648	Ball bearing
304	23042742	Bail arm cover	0910041	0910041	Ball bearing
305	23050206	Kick lever	0910051	0910051	Ball bearing
307	23071770	Bail holder	0910093	0910093	Ball bearing
309	23090051	Bail arm support pin	0910335	0910335	Ball bearing
310	23100102	Compression spring	0920310	0920310	Washer
313	23131974	Bail wire assy.	0920373	0920373	Washer
315	23150086	Line roller	0920376	0920376	Washer
316	23160014	Line roller bushing	0920590	0920590	Washer
316-1	23160010	Line roller bushing	0920154	0920154	Washer
317	23170014	Line roller washer	0920237	0920237	Washer
318	23180005	Rotor nut	0930433	0930433	Screw
400	240016279	Spool assy.	0930541	0930541	Screw
405	24050042	Drag washer retainer	09301252	09301252	Screw
407	24070047	Extension spring	0930209	0930209	Screw
500	25006613	Handle assy.	0930044	0930044	Screw
504	25040007	Handle screw cap washer	0930471	0930471	Screw
513	25130852	Handle cap	09301462	09301462	Screw
600	26003034	Drag knob assy.	09301265	09301265	Screw
610	26100011	Drag washer	0930794	0930794	Screw
611	26110005	Eared washer	0930429	0930429	Screw
612	26120007	Key washer	0930838	0930838	Screw
700	27000318	Drive gear	0930673	0930673	Screw
702	27020907	Pinion gear			

209OKA09040301