




SVI-40-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004640	Main body	702	27020822	Pinion gear
105	21050027	Pinion bearing fixed plate	705	27050105	Transmission gear
105-1	21056578	Pinion bearing fixed bushing	708	27080095	Oscillating slider
105-2	21050165	Pinion bearing fixed bushing	716	27160007	Oscillation slider plate
108	21081637	Cap	718	27180705	Main shaft
200	22004731	Side plate	719	27190025	Click gear
201	22011238	Main body decoration	722	27220009	Click gear washer
201-1	22011239	Side plate decoration	725	27250020	Transmission gear bushing
300	23005014	Rotor	800	28000241	Anti-reverse/anti-re lever
301	23012360	Bail arm	800-1	28000322	Anti-reverse/anti-re lever
304	23042743	Bail arm cover	801	28010024	Anti-re lever spring
305	23050207	Kick lever	0910649	0910649	Ball bearing
307	23071770	Bail holder	0910041	0910041	Ball bearing
309	23090051	Bail arm support pin	0910051	0910051	Ball bearing
310	23100102	Compression spring	0910093	0910093	Ball bearing
313	23131694	Bail wire assy.	0910335	0910335	Ball bearing
315	23150086	Line roller	0920540	0920540	Washer
316	23160014	Line roller bushing	0920373	0920373	Washer
316-1	23160010	Line roller bushing	0920376	0920376	Washer
317	23170014	Line roller washer	0920590	0920590	Washer
318	23180005	Rotor nut	0920154	0920154	Washer
400	240016275	Spool assy.	0920237	0920237	Washer
405	24050042	Drag washer retainer	0930044	0930044	Screw
407	24070009	Extension spring	0930575	0930575	Screw
500	25006735	Handle assy.	0930171	0930171	Screw
504	25040007	Handle screw cap washer	09301252	09301252	Screw
513	25130852	Handle cap	0930209	0930209	Screw
600	26003034	Drag knob assy.	0930055	0930055	Screw
610	26100011	Drag washer	0930471	0930471	Screw
611	26110005	Eared washer	09301265	09301265	Screw
612	26120006	Key washer	0930643	0930643	Screw
612-1	26120054	Key washer	0930429	0930429	Screw
612-2	26120007	Key washer	0930838	0930838	Screw
700	27000322	Drive gear	0930663	0930663	Screw

209OKA09040401