




SVI-55-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21009357	Main body	700	27000328	Drive gear
105	21050241	Pinion bearing fixed plate	702	27020853	Pinion gear
105-1	21056581	Pinion bearing fixed plate	705	27050100	Transmission gear
105-2	21050140	Pinion bearing fixed bushing	708	27080097	Oscillating slider
108	21081595	Cap	716	27160009	Oscillation slider plate
200	22004686	Side plate	718	27180700	Main shaft
201	22011171	Side plate decoration	719	27190025	Click gear
201-1	22011170	Main body decoration	722	27220009	Click gear washer
300	23005015	Rotor	725	27250020	Transmission gear bushing
301	23012399	Bail arm	800	28000255	Anti-reverse/anti-re lever
304	23042744	Bail arm cover	800-1	28000448	Anti-reverse/anti-re lever
305	23050210	Kick lever	801	28010039	Anti-re lever spring
307	23071771	Bail holder	0910530	0910530	Ball bearing
309	23090037	Bail arm support pin	0910281	0910281	Ball bearing
310	23100070	Compression spring	0910093	0910093	Ball bearing
313	23131696	Bail wire assy.	0910015	0910015	Ball bearing
315	23150075	Line roller	0910335	0910335	Ball bearing
316	23160011	Bushing	0920589	0920589	Washer
317	23170010	Line rollerwasher	0920545	0920545	Washer
318	23180001	Rotor nut	0920151	0920151	Washer
400	240016280	Spool assy.	0920150	0920150	Washer
405	24050031	Drag washer retainer	0920246	0920246	Washer
407	24070006	Extension spring	0930044	0930044	Screw
412	24120055	Spool bushing	0930575	0930575	Screw
500	25006614	Handle assy.	0930171	0930171	Screw
504	25040007	Handle screw cap washer	0930763	0930763	Screw
513	25130852	Handle cap	0930209	0930209	Screw
600	26003034	Drag knob assy.	0930471	0930471	Screw
610	26100053	Drag washer	09301271	09301271	Screw
611	26110021	Eared washer	0930643	0930643	Screw
612	26120049	Key washer	0930964	0930964	Screw
612-1	26120056	Key washer	0930819	0930819	Screw
612-2	26120050	Key washer	0930623	0930623	Screw

209OKA09040551