



TESORO-12S

KEY NO	PART NO	PARTS NAME	KEY NO	PART NO	PARTS NAME	KEY NO	PART NO	PARTS NAME
100	11004959	Main body assy.	606	26060017	Click pawl	910	0910535	Ball bearing
114	11140037	Clamp	609	16090007	Tensioned washer	910	0910668	Bearing
114-1	11140082	Reel clamp assy.	609-1	16090028	Tensioned washer	920	0920091	Washer
115	11150030	Clamp screw	610	16100076	Drag washer	920	09201005	Washer
116	11160017	Clamp nut	610-1	16100078	Drag washer	920	0920157	Washer
117	11170037	Handle nut	611	16110079	Eared washer	920	0920207	Washer
200	12002125	Main side plate assy.	612	16120109	Key washer	920	0920283	Washer
201	12010077	Anti-re pawl	612-1	16120110	Key washer	920	0920304	Washer
202	12020049	Ratchet	612-2	16120111	Key washer	920	0920423	Washer
207	12070131	Holded plate	615	16150262	Star drag	920	0920455	Washer
211	12110030	PIN	616	16160016	Star drag bushing	920	0920551	Washer
216	12160008	Extened spring	619	16190003	Washer	920	0920613	Washer
219	12190067	Main side plate bushing	619-1	16190007	WASHER	920	0920614	Washer
241	12410005	Compression spring	700	17000467	Drive gear	920	0920626	Washer
241-1	12410007	Compression spring	701	17010329	Drive gear shaft assy.	920	0920627	Washer
241-2	12410026	Compression spring	702	17020683	Pinion gear	920	0920664	Washer
242	12420012	Compression spring	720	17200009	Drive gear shaft bushing	920	0920665	Washer
303	13030078	Click button	720-1	17200010	Drive gear shaft bushing	930	09301219	Screw
304	13040032	Click pawl	721	47210004	Drive gear bushing	930	09301420	Screw
305	13050016	Click pawl spring	724	17240001	Click pawl	930	09301453	Screw
316	33160002	Packing washer	800	18000029	Clutch shaft assy.	930	09301458	Screw
400	14001110	Spool assy.	801	18010027	Clutch spring	930	09301514	Screw
405	24050004	Drag washer retainer	802	18020186	Clutch bar assy.	930	09301521	Screw
405-1	24050005	Drag washer retainer	804	18040024	Clutch slider	930	09301528	Screw
405-2	24050008	Drag washer retainer	805	18050009	Clutch yoke	930	09301622	Screw
500	15000528	Handle arm assy.	815	18150008	Clutch bar screw	940	0940068	Oil seal
500-1	15000577	Handle arm	900	19000001	"E" retainer	940	0940072	Oring
509	15090104	Handle knob assy.	901	19010031	C retainer			
600	16000188	Cast control cap	902	19020004	Tool			
600-1	16000189	Cast control cap	912	19120037	Cover			
604	16040012	Drag click pawl over	910	0910432	Ball bearing			