



TG - 10S Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000707	1110007304003	MAIN BODY ASSY.		613	16130005	11613004-06	COMPRESSION SPRING	
200	12000582	1120005904004	HANDLE SIDE PLATE ASSY.		700	17000183	11700021-26004	DRIVE GEAR	3018
201	12010012	11201009-06001	ANTI-RE PAWL		700	17000174	1170002102	DRIVE GEAR	
203	12030004	11203003-01001	CONTROL PIN		701	17010057	11701032-16001	DRIVE GEAR SHAFT	
204	12040002	11204002-06	COMPRESSION SPRING		702	17020230	11702027-36003	PINION GEAR	3018
206	12060007	11206007-03001	LEVER DRAG STOPPER CAP		702	17020220	1170202702	PINION GEAR	
217	12170010	11217005-06001	ANTI-RE PAWL SPRING		717	17170004	11717003-06	MAIN SHAFT PIN	
300	13000314	1130004414004	SIDE PLATE ASSY.		718	17180087	11718053-16001	MAIN SHAFT	
303	13030037	11303011-03001	CLICK BUTTON		723	17230004	11723001-11001	SILENT RING	3019
304	13040001	11304003-06	CLICK PAWL	3020	723	17230005	11723001-21001	SILENT RING	
304	13040009	11304011-06001	CLICK PAWL	3107	9101	0910103	01081605-615	BALL BEARING	3032
304	13040015	11304011-16001	CLICK PAWL		9101	0910146	01091705-616	BALL BEARING	
305	13050006	11305002-06001	CLICK PAWL SPRING		9104	0910030	01061505-6	BALL BEARING	3032
400	14000258	11400053-04003A	SPOOL	3031	9104	0910037	01061505-616	BALL BEARING	
400	14000262	11400053-14003A	SPOOL		9105	0910030	01061505-6	BALL BEARING	
401	14010024	11401009-05001	SPOOL CLICK GEAR		912	19120007	11912004-04002	COVER BOARD	
405	14050019	11405014-11	SPOOL COVER	3031	913	19130001	11913001-05907	SPRING WASHER	
405	14050018	11405014-01001	SPOOL COVER		913-1	19130005	11913002-06001	SPRING WASHER	
405-1	14050016	11405013-07001	SPOOL COVER		9201	0920025	0212x15x0.5-6	WASHER	
500	15000099	1150002214003	HANDLE ASSY.		9201-1	0920028	0212x15x0.7-6	WASHER	
501	15010013	11501009-26	HANDLE NUT		9203	0920126	026.05x9x0.5-6	WASHER	
507-1	15070029	11507008-05001	TRANSMISSION PIN		9206	0920079	023.95x10.8x0.5-7	WASHER	
513	15130013	11513009-06	HANDLE COVER		9208	0920004	0210.1x23.8x1-00	WASHER	
516	15160019	11516005-06	HANDLE NUT RETAINER		9215	0920074	023.1x5.9x1-1	WASHER	
600	16000027	11600013-03907	CAST CONTROL CAP		9303	0930188	03312.6x5-61	SCREW	
601	16010001	11601001-06	COMPRESSION SPRING		9304	0930211	03325.2x2x5-61	SCREW	
602	16020006	11602001-15001	ADJUST BLOCK		9305	0930337	03613.0x7.5-61	SCREW	
602-1	16020010	11602005-01001	ADJUST BLOCK		9307	0930129	03212.6x5.5-617	SCREW	
603	16030001	11603001-07	O RING		9311	0930340	03613.0x9-617	SCREW	
605	16050081	11605014-14004	LEVER DRAG		9313	0930193	03312.68-61	SCREW	
607	16070033	11607009-16002	PINION GUARD		9314	0930129	03212.6x5.5-617	SCREW	
608	16080004	11608003-06	DRAG WASHER RETAINER		9319	0930196	03312x5-61	SCREW	
609	16090008	11609007-05907	DRAG SPRING WASHER		9329	0930199	03313.5x4.5-617	SCREW	
611	16110028	11611013-01001	EARED WASHER		9401	19000006	11900007-06001	E RETAINER	
611-1	16110027	11611013-00	DRAG WASHER	3001	9402	19000001	11900001-06	E RETAINER	
611-1	16110042	1161101301	DRAG WASHER		9502	19010016	11901009-06001	C RETAINER	
612	16120021	11612010-062	KEY WASHER						