



TG - 30 - II Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000313	1110002614003	MAIN BODY		612	16120017	11612009-06003	KEY WASHER	
102	11020017	11102007-04002	BODY FOOT		613	16130012	11613010-06	COMPRESSION SPRING	
108	11080009	11108006-06	HANGER		700	17000036	1170000902	DRIVE GEAR	
117	11170006	11117004-13	CLICK BUTTON RETAINER NUT		700	17000049		DRIVE GEAR	3014
200	12000410	1120003314004	HANDLE SIDE PLATE ASSY.		700-1	17000070	11700010-26004	DRIVE GEAR	3014
201	12010012	11201009-06001	ANTI-RE PAWL		700-1	17000057	1170001002	DRIVE GEAR	
203	12030003	11203002-01001	CONTROL PIN		701	17010215	0	DRIVE GEAR SHAFT	
204	12040002	11204002-06	COMPRESSION SPRING		702	17020051	1170201402	PINION GEAR	
204-1	12040006	11204003-05001	COMPRESSION SPRING		702	17020067	11702014-26003	PINION GEAR	3018
204-2	12040011	11204004-06	COMPRESSION SPRING		702-1	17020088	11702015-26003	PINION GEAR	3018
205	12050014	11205004-060041	DECORATION PLATE		702-1	17020079	1170201502	PINION GEAR	
206	12060002	11206001-03001	LEVER DRAG STOPPER CAP		717	17170004	11717003-06	MAIN SHAFT PIN	
206-1	12060003	11206002-03907	LEVER DRAG STOPPER CAP		718	17180068	11718032-16001	MAIN SHAFT	
206-2	12060005	11206005-03001	LEVER DRAG STOPPER CAP		723	17230004	11723001-11001	SILENT RING	3019
207	12070012	11207008-04001	HOLD PLATE	3029	723	17230005	11723001-21001	SILENT RING	
207	12070040	1120703202	HOLD PLATE		913	19130001	11913001-05907	SPRING WASHER	
215	12150011	11215010-03001	HOLD PLATE BUSHING	3046	913-1	19130005	11913002-06001	SPRING WASHER	
215	12150010	1121501001	HOLD PLATE BUSHING		9101	0910140	01091705-6	BALL BEARING	3032
217	12170009	11217004-06001	ANTI-RE PAWL SPRING		9101	0910146	01091705-616	BALL BEARING	
300	13000196	11300029-04004	SIDE PLATE		9104	0910110	01081906-616	BALL BEARING	3032
303	13030054	NO	CLICK BUTTON ASSY.		9104	0910110	01081906-616	BALL BEARING	
304	13040007	11304007-06001	CLICK PAWL		9105	0910030	01061505-6	BALL BEARING	
400	14000161	11400035-04004A	SPOOL	3031	9201	0920025	0212x15x0.5-6	WASHER	
400	14000170	11400035-14003A	SPOOL		9201-1	0920028	0212x15x0.7-6	WASHER	
405	14050013	11405010-11	SPOOL COVER	3031	9203	0920161	028x10.5x0.8-6	WASHER	
405	14050012	11405010-01001	SPOOL COVER		9208	0920005	0210.1x23.8x1-9	WASHER	
405-1	14050016	11405013-07001	SPOOL COVER		9215	0920074	023.1x5.9x1-1	WASHER	
500	15000082	11500017067B	HANDLE ASSY.		9216	0920153	028.1x12x0.5-1	WASHER	
501	15010010	11501008-26	HANDLE NUT		9217	0920046	0217.2x24x2-10	WASHER	
507	15070021	11507006-11	PUSH BUTTON		9218	0920098	024.6x8x0.2-6	WASHER	
507-1	15070013	11507004-05907	TRANSMISSION PIN		9301	0930341	03613x16.5-617	SCREW	
508	15080002	11508002-06	PUSH BUTTON SPRING		9302	0930188	03312.6x5-61	SCREW	
513	15130013	11513009-06	HANDLE COVER		9302-1	0930084	032100510	SCREW	
516	15160010	11516004-01	HANDLE NUT RETAINER		9304	0930211	03325.2x2x5-61	SCREW	
517	15170004	11517003-06001	TRANSMISSION PIN		9305	0930003	03112.6x10-61	SCREW	
517-1	15170009	11517004-03001	TRANSMISSION PIN		9306	0930161	03213x8-61003	SCREW	
600	16000027	11600013-03907	CAST CONTROL CAP		9307	0930110	032101907	SCREW	
601	16010001	11601001-06	COMPRESSION SPRING		9309	0930250	03413x6-61	SCREW	
602	16020006	11602001-15001	ADJUST BLOCK		9310	0930347	03614x10-617	SCREW	
603	16030001	11603001-07	O RING		9311	0930331	03613.0x10-617	SCREW	
605	16050057	11605011-04912	LEVER DRAG		9314	0930241	03412.6x7.6-617	SCREW	
607	16070033	11607009-16002	PINION GUARD		9329	0930199	03313.5x4.5-617	SCREW	
608	16080004	11608003-06	DRAG WASHER RETAINER		9402	19000004	11900004-06	E RETAINER	
609	16090007	11609006-05907	SPRING WASHER		9403	29000001	12900001-06	E RETAINER	
611	16110032	11611014-01001	DRAG WASHER		9502	19010016	11901009-06001	C RETAINER	
611-1	16110043	11611014-002	DRAG WASHER						