



TG - 50 - II Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000613	1110004114006	MAIN BODY ASSY.		609	16090007	11609006-05907	SPRING WASHER	
108	11080007	11108004-0681	HANGER		611	16110034	11611015-01001	DRAG WASHER	
117	11170006	11117004-13	CLICK BUTTON RETAINER NUT		611-1	16110044	11611015-01	DRAG WASHER	
200	12000556	1120004104004	HANDLE SIDE PLATE ASSY.		612	16120024	11612011-062	KEY WASHER	
201	12010012	11201009-06001	ANTI-RE PAWL		613	16130007	11613005-16	COMPRESSION SPRING	
203	12030003	11203002-01001	CONTROL PIN		700	17000120	1170001502	DRIVE GEAR	
204	12040002	11204002-06	COMPRESSION SPRING		700-1	17000135	1170001602	DRIVE GEAR	
204-1	12040007	11204003-05002	COMPRESSION SPRING		701	17010216	0	DRIVE GEAR SHAFT	
204-2	12040011	11204004-06	COMPRESSION SPRING		702	17020133	1170201902	PINION GEAR	
205	12050027	11205009-060011	DECORATION PLATE		702-1	17020117	1170201802	PINION GEAR	
206	12060007	11206007-03001	LEVER DRAG STOPPER CAP		717	17170004	11717003-06	MAIN SHAFT PIN	
206-1	12060003	11206002-03907	LEVER DRAG STOPPER CAP		718	17180044	11718018-16001	MAIN SHAFT	
206-2	12060005	11206005-03001	LEVER DRAG STOPPER CAP		723	17230004	11723001-11001	SILENT RING	3019
207	12070029	11207014-04001	HOLD PLATE	3029	723	17230005	11723001-21001	SILENT RING	
207	12070042	1120703302	HOLD PLATE		9101	0910174	01102005-6	BALL BEARING	3032
215	12150007	11215006-13	HOLD PLATE BUSHING		9101	0910180	01102005-616	BALL BEARING	
217	12170009	11217004-06001	ANTI-RE PAWL SPRING		9104	0910106	01081906-6	BALL BEARING	3032
303	13030054	NO	CLICK BUTTON ASSY		9104	0910110	01081906-616	BALL BEARING	
304	13040007	11304007-06001	CLICK PAWL		9105	0910097	01081605-6	BALL BEARING	
400	14000205	11400037-04004A	SPOOL	3031	913	19130001	11913001-05907	SPRING WASHER	
400	14000211	11400037-14003A	SPOOL		913-1	19130005	11913002-06001	SPRING WASHER	
405	14050021	11405015-01001	SPOOL COVER	3031	9201	0920040	0214x18x0.5-6	WASHER	
405	14050021	11405015-01001	SPOOL COVER		9201-1	0920042	0214x18x0.7-6	WASHER	
405-1	14050016	11405013-07001	SPOOL COVER		9203	0920161	028x10.5x0.8-6	WASHER	
500	15000082	11500017067B	HANDLE ASSY.		9208	0920004	0210.1x23.8x1-00	WASHER	
501	15010010	11501008-26	HANDLE NUT		9214	0920080	023.9x7x1-7	WASHER	
507	15070021	11507006-11	PUSH BUTTON		9215	0920074	023.1x5.9x1-1	WASHER	
507-1	15070027	11507007-05907	DRIVE GEAR TRANSMISSION PIN		9216	0920153	028.1x12x0.5-1	WASHER	
508	15080002	11508002-06	PUSH BUTTON SPRING		9217	0920054	0219.2x25x2-10	WASHER	
513	15130012	11513008-06	HANDLE COVER		9301	0930334	03613.0x18-617	SCREW	
516	15160010	11516004-01	HANDLE NUT RETAINER		9302	0930188	03312.6x5-61	SCREW	
517	15170004	11517003-06001	TRANSMISSION PIN		9304	0930211	03325.2x2x5-61	SCREW	
517-1	15170009	11517004-03001	TRANSMISSION PIN		9305	0930004	03112.6x13-61	SCREW	
600	16000027	11600013-03907	CAST CONTROL CAP		9306	0930161	03213x8-61003	SCREW	
601	16010001	11601001-06	COMPRESSION SPRING		9307	0930110	032101907	SCREW	
602	16020006	11602001-15001	ADJUST BLOCK		9309	0930037	03114.0x10-61	SCREW	
602-1	16020010	11602005-01001	ADJUST BLOCK		9314	0930229	03412.6x5.5-617	SCREW	
603	16030001	11603001-07	O RING		9329	0930199	03313.5x4.5-617	SCREW	
605	16050065	11605012-14004	LEVER DRAG		9402	19000004	11900004-06	E RETAINER	
607	16070037	11607011-06002	PINION GUARD	3031	9403	29000001	12900001-06	E RETAINER	
607	16070038	11607011-16002	PINION GUARD		9502	19010017	1190101001	C RETAINER	
608	16080004	11608003-06	DRAG WASHER RETAINER						