



TS - 50 Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000400	1110003014008	MAIN BODY ASSY.		613	16130007	11613005-16	COMPRESSION SPRING	
108	11080007	11108004-0681	HANGER		700	17000158	11700017-16004	DRIVE GEAR	3049
117	11170006	11117004-13	CLICK BUTTON RETAINER NUT		700	17000150	1170001702	DRIVE GEAR	
200	12000527	1120003804009	HANDLE SIDE PLATE ASSY.		701	17010050	11701018-06	DRIVE GEAR SHAFT	3049
201	12010012	11201009-06001	ANTI-RE PAWL		701	17010211	11701018-061	DRIVE GEAR SHAFT	
205	12050022	11205006-0611	DECORATION PLATE		702	17020194	11702022-26003	PINION GEAR	3049
206	12060002	11206001-03001	LEVER DRAG STOPPER CAP		702	17020182	1170202202	PINION GEAR	
206-1	12060003	11206002-03907	LEVER DRAG STOPPER CAP		702-1	17020197	11702023-06001	PINION GEAR	
207	12070029	11207014-04001	HOLD PLATE	3029	717	17170004	11717003-06	MAIN SHAFT PIN	
207	12070042	1120703302	HOLDED PLATE		718	17180044	11718018-16001	MAIN SHAFT	
215	12150008	11215007-03	HOLD PLATE BUSHING		723	17230004	11723001-11001	SILENT RING	3019
217	12170009	11217004-06001	ANTI-RE PAWL SPRING		723	17230005	11723001-21001	SILENT SPRING	
303	13030054		CLICK BUTTON ASSY.		9101	0910174	01102005-6	BALL BEARING	
304	13040007	11304007-06001	CLICK PAWL		9102	0910044	01071304-6	BALL BEARING	
400	14000205	11400037-04004A	SPOOL	3031	9104	0910106	01081906-6	BALL BEARING	
400	14000212	11400037-14004	SPOOL ASSY.		9105	0910097	01081605-6	BALL BEARING	
405	14050021	11405015-01001	SPOOL COVER	3031	913	19130001	11913001-05907	SPRING WASHER	
405	14050021	11405015-01001	SPOOL COVER		913-1	19130005	11913002-06001	SPRING WASHER	
405-1	14050016	11405013-07001	SPOOL COVER		9201	0920040	0214x18x0.5-6	DRIVE GEAR SHAFT WASHER	
500	15000081	11500017067A	HANDLE ASSY.		9203	0920161	028x10.5x0.8-6	PRESSURE LOAD BLOCK WASHER	
501	15010013	11501009-26	HANDLE NUT		9208	0920005	0210.1x23.8x1-9	LEVEL DRAG WASHER	
507-1	15070029	11507008-05001	DRIVE GEAR TRANSMISSION PIN		9214	0920080	023.9x7x1-7	HANGER WASHER	
513	15130012	11513008-06	HANDLE COVER		9215	0920074	023.1x5.9x1-1	SIDE PLATE SCREW WASHER	
516	15160019	11516005-06	HANDLE NUT RETAINER		9216	0920153	028.1x12x0.5-1	CLICK BUTTON RETAINER WASHER	
600	16000027	11600013-03907	CAST CONTROL CAP		9301	0930020	03113.0x18-61	MAIN SIDE PLATE SCREW	
601	16010001	11601001-06	COMPRESSION SPRING		9302	0930188	03312.6x5-61	HOLD PLATE SCREW	
602	16020006	11602001-15001	ADJUST BLOCK		9305	0930003	03112.6x10-61	LEVER DRAG STOPPER CAP SCREW	
603	16030001	11603001-07	O RING		9306	0930086	032100512	DECORATION PLATE SCREW	
605	16050056	11605011-04909	LEVEL DRAG		9307	0930129	03212.6x5.5-617	HANDLE ARM RETAINER SCREW	
607	16070037	11607011-06002	PINION GUARD	3031	9309	0930037	03114.0x10-61	HANGER SCREW	
607	16070038	11607011-16002	PINION GUARD		9314	0930229	03412.6x5.5-617	CLCK GEAR SCREW	
608	16080004	11608003-06	DRAG WASHER RETAINER		9329	0930199	03313.5x4.5-617	SPOOL COVER SCREW	
609	16090007	11609006-05907	DRAG SPRING WASHER		9402	19000004	11900004-06	E RETAINER FOR MAIN SHAFT	
611	16110026	11611011-067	EARED WASHER		9502	19010017	1190101001	C RETAINER FOR GEAR SHAFT	
612	16120024	11612011-062	KEY WASHER						