



V - 200LX Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	41000274	14100017-04004	LOW OKM0026		703	47030013	14703004-01001	WORM SHAFT GUARD	
105	41050003	14105002-01002	WORM SHAFT BUSHING		705	47050008	14705003-01002	TRANSMISSION GEAR	
117	11170013	11117005-03002	NUT	3025	705-1	47050010	14705004-01002	TRANSMISSION GEAR	
119	41190007	14119002-01726	BODY COVER		705-1	47050009	14705004-01002	TRANSMISSION GEAR	3101
200	42000123	1420000804004	HANDLE SIDE PLATE		711	47110019	1471100201003A	GUIDE SLIDE BASE ASSY	
202	42020003	14202002-06002	RATCH		712	47120007	14712004-03001	WORM SHAFT	
206	42060003	14206002-01002	CONTROL PIN CAP		713	47130005	14713002-04001	LINE GUIDE PAWL CAP	
207	42070001	14207001-01001	HOLDED PLATE		715	47150003	14715002-06001	LINE GUIDE PAWL	
220	42200004	14220002-06001	SIDE PLATE HOLDED SCREW	3107	720	47200004	14720002-06002	DRIVE GEAR SHAFT BUSHING	
220	42200008	14222002-06001	SIDE PLATE HOLDED SCREW		725	47250001	14725001-06001	TRANSMISSION GEAR PIN	
226	42260001	14226001-03001	CONTROL PIN		800	48000006	14800002-06001	CLUTCH SHAFT	
300	43000078	14300005-0A102	SIDE PLATE		801	48010005	14801004-06001	CLUTCH SHAFT SPRING	
302	43020004	14302001-1	WASHER		804	48040005	14804004-06001	CLUTCH SLIDER	
304	43040003	14304003-06001	CLICK PAWL	3052	804-1	48040010	14804006-02001	CLUTCH SLIDER	
304	43040005	14304003-16001	CLICK PAWL		805	48050008	14805004-01002	PINION GEAR YOKE	
306	43060002	14306002-03001	CLICK BUTTON SPRING PIN		806	48060002	14806002-06001	YOKE SPRING	
313	43130002	14313002-06001	VICE SIDE PLATE FIXER		807	48070007	14807004-01001	YOKE BRAKED PLATE	
314	43140001	14314001-06001	CONTROL PIN		808	48080005	14808004-06001	YOKE BRAKED PLATE SPRING	
315	43150001	14315001-01003	SIDE HOLDED PLATE		809	48090007	14809002-01003	CLUTCH BAR WASHER	
318	43180001	14318001-03001	CONTROL PIN BUSHING		812	48120004	14812004-06001	BRAKED PLATE HOLDER	
400	44000101	1440001004002	SPOOL ASSY.		813	48130001	14813001-07003	CLUTCH BAR CAP	
400-1	44000095	1440000904002	SPOOL ASSY		9103	0910163	01101612-62	BALL BEARING	3050
401	44010005	14401003-01001	SPOOL CLICK GEAR		9103	0910170	01101612-63	BALL BEARING	
500	45000042	1450000404002	HANDLE ARM ASSY		9103	0910207	01030804-61	BALL BEARING	
516	45160015	14516002-0A003	HANDLE NUT RETAINER		9103	0910235	01050903-61	BALL BEARING	
600	46000021	14600003-04005A	CAST CONTROL CAP		9106	0910005	01031004-601	BALL BEARING	
603	46030003	14603002-07	O RING		9108	0910335	01040725-61	BALL BEARING	
604	46040004	14604002-02001	CONTROL CLICK		9201	0920105	025.1x10.5x.2-6	WASHER	
608	46080003	14608002-06001	RETAINER		9201-1	0920162	028x10x0.5-6	WASHER	
608-1	46080002	14608001-06001	RETAINER		9201-2	0920326	028.1x12x0.5-0	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER	3112	9204	0920292	025.9x12x0.2-6	WASHER	
609	16090009	11609003-06002	DRAG SPRING WASHER		9204	0920293	025.9x12x0.5-6	WASHER	3025
610	16100018	11610004-006A	DRAG WASHER		9205	0920332	028.2x20x1-9	WASHER	
610-1	16100007	11610003-006	DRAG WASHER	3052	9207	0920066	022x4.9x0.2-3	WASHER	
610-1	16100037	1161000301	DRAG WASHER		9301	0930378	03112x8-617	SCREW	
610-2	16100038	1161000401	DRAG WASHER		9301-1	0930355	03112.6x10-617	SCREW	
611	16110006	11611005-061	EARED WASHER		9302	0930226	03412.6x4-61	SCREW	
612	16120030	11612007-06004	KEY WASHER		9309	0930704	03412x4-61	SCREW	
612-1	16120027	11612007-06001	KEY WASHER		9314	0930503	03212x6-617	SCREW	
615	46150049	14615004-04002A	STAR DRAG		9314	0930508	03212x8-617	SCREW	3112
618	46180002	14618002-07	WASHER		9314-1	0930146	03212x3.2-61	SCREW	
619	46190003	14619002-01001	WASHER		9316	0930763	03422.6x6.5-61	SCREW	
700	47000018	14700006-03003	DRIVE GEAR		9401	29000001	12900001-06	E RETAINER	
701	47010012	14701005-03004	DRIVE GEAR SHAFT		9404	19000002	11900002-06	E RETAINER	
702	47020032	14702009-03002	PINION GEAR						