




**KEY
NO.**

DESCRIPTION

1	Right Side Plate Assembly
2	Quadrant Ring
2A	Quadrant Ratchet Plate
4A	Thrust Washer
4B	Cam Thrust Washer
5H	Main Gear (High Speed)
5L	Main Gear (Low Speed)
7	Metal Drag Washer
9	Spacing Sleeve
13	Pinion Gear
13B	Spool Sleeve
14	Dog Spring (2 req.)
15	Dog (2 req.)

**PART
NO.**

001 016VS
002 016VS
002A016VS
004 012LT
004 030VS
005 016VSHSX
005 016VSLSX
007 016VS
009 016VS
013 016VSX
013B016VS
014 016S
015 050

**KEY
NO.**

DESCRIPTION

18	Disc Clutch Spring (4 req.)
18A	Click Spring
18H	Shift Spring (Heavy)
18L	Shift Spring (Light)
19	Eccentric Cam
20	Ball Bearing (2 req.)
21	Eccentric Lever
22	Dog Spring Screw (2 req.)
23	Screw
24	Handle Complete
24A	Handle Blank
24C	Handle Knob Cap
25	Knob Assembly

**PART
NO.**

018 016VS
018 525
018H030VS
018L030VS
019 016VS
020 722
021 016VS
022 109
023 030VS
024 016VS
024A 016VS-1
024C113HN
025 113HN

**KEY
NO.**

DESCRIPTION

26	Bearing (2 req.)
27	Left Side Plate-Assembly
29L	Spool
30	Stand
31	Short Screw (4 req.)
33	Rod Clamp
34	Clamp Screw (2 req.)
34C	Rod Clamp Screw w/Nut
35	Click Tongue
36	Click Knob
36A	Click Cam Follower
36S	Click Cap
38	Side Plate Screw (3 req.)
39	Side Plate Screw (3 req.)
41	Bearing Spring
41A	Drag Spring
50	Shield
52	Retaining Ring
54	Harness Lug (2 req.)
54A	Harness Lug Plug (2 req.)
62	Click Spring
62A	Dog Spring
63	Screw
63A	Screw
67	Pinion Gear Washer
67A	Screw
69	Locating Pin (2 req.)
69A	Retaining Ring
69B	Retaining Ring
69C	Retaining Ring
81	Ratchet
82	Shim
91	Handle Rivet
101	Ratchet Screw (4 req.)
110A	Ring
110B	Shift Base
110C	Shift Button Retainer
112	Eccentric Lever Knob Assembly
112A	Knob Sleeve
112B	Eccentric Knob Screw
117A	Inner Drive Plate
117D	Outer Drive Plate
118	Screw (4 req.)
119	Shift Plate
124	Bridge Cover Assembly
128A	Drive Plate
133	Retaining Plate
134	Gear Stud
141	Cam Follower
143	Preset Screw
149	Rod Clamp Nut (2 req.)
149A	Nut
156	Drag Cover
156A	Pin
156B	Plate
161	Locating Pin Spring (2 req.)
170	Catch Assembly
171	Shift Plunger
172	Shift Button
172A	Spacer
183	Tube Frame
195	Retaining Ring
195A	Retaining Ring

**PART
NO.**

026N040
027 016VS
029L016VS
030 016VS
031T070
033 016VS
034 016VS
034C114HLW
035 016VSX
036 016VS
036A016VS
036S016VS
038 016VS
039 016VS
041 109
041 060
050 030VS
052 016VS
054 016S
054A016VS
062 050
014 099
031 016VS
063A016VS
067 016VS
044 710
069 012VS
195 024KG
069C245
069 016VS
081 016VS
082 024KG
091 016VS
101 030
110A030VS
110B030VS
110C030VS
112 030VS
112A030VS
112B070
117AN016VS
117DN016VS
118 080
119 024KG
124L016VS
128A024KG
133 030VS
134 016VS
141 030VS
143 016VS
149 045
149 200
156 016VS
156A016VS
156B016VS
162 050
170 030VS
171 015KG
172 030VS
172A015KG
183 016VSX
195 040
067 030VS