




PARTS LIST FOR MODEL 130VSX



Penn Reel Parts list for:

KEY PART NO.	NO.	DESCRIPTION
1	1-130VS	RIGHT SIDE PLATE ASSEMBLY
2	2-130VS	QUADRANT RING
2A	2A-130VS	DRAG LEVER RATCHET
4	4-130VS	CAM THRUST WASHER (2 REQ.)
4A	4A-70	LEVER THRUST WASHER
5H	5-130VSHS	MAIN GEAR HIGH SPEED
5L	5-130VSLS	MAIN GEAR LOW SPEED
6DN	6DN-130	DRAG WASHER ASSEMBLY (DURA DRAG)
7A	7A-130VS	DRAG PLATE
13	13-130ST	PINION GEAR ASSEMBLY
13A	13A-130	PINION SLEEVE (SHORT)
13	13B-130VS	SPOOL SLEEVE (LONG)
14	49-710	DOG SPRING (3 REQ.)
15	15-130	DOG (3 REQ.)
18	18-130	DISC CLUTCH SPRINGS (2 REQ.)
18C	18C-15KG	SHIFT BUTTON SPRING (2 REQ.)
18H	18H-30VS	SHIFT SPRING (HEAVY)
18L	18L-30VS	SHIFT SPRING (LIGHT)
19	19-130VS	ECCENTRIC CAM
21	21-130VS	ECCENTRIC LEVER
23	23-130VS	HANDLE SCREW
23A	23-750	SCREW, MAIN GEAR (7 REQ.)
24	24-130VS	HANDLE COMPLETE
24B	24-130VS-1	HANDLE ARM (ONLY)
24C	24C-80ST	HANDLE KNOB CAP
25	25-80ST	HANDLE KNOB
27	27-130VS	LEFT SIDE PLATE ASSEMBLY
29	29-130VS	SPOOL
30	30-130VS	STAND
31	31T-70	SCREW (5 REQ.)
33	33-130ST	RINGED ROD CLAMP
33C	33C-130VSX	ROD CLAMP KIT
34	34-130	CLAMP SCREW (2 REQ.)
34C	34-130VS	ROD CLAMP SCREW W/ NUT
35	35-130VS	CLICK TONGUE
36	36-700	CLICK BUTTON NUT
36C	36C-130VS	CLICK BUTTON ASSEMBLY COMPLETE
36N	36N-50	CLICK BUTTON
36S	36S-80ST	CLICK BUTTON CAP
38	38-130VS	RIGHT SIDE PLATE SCREWS (10 REQ.)
38A	38-710	CLICK RETAINER NUT
39	39-130VS	LEFT SIDE PLATE SCREW (10 REQ.)
41	41-130VS	LEFT SIDE BEARING SPRING
41A	41A-130VS	RIGHT SIDE BEARING SPRING
44	44-710	DRIVE PLATE SCREW (2 REQ.)
49	49-710	DOG SPRING (3 REQ.)
52	52-910	RETAINING RING
54	54-130VS	HARNES LUG (2 REQ.)
54A	54A-130VS	ROD BRACE LUG (4 REQ.)
54B	54B-80VS	LUG SCREW (8 REQ.)
55	55-80ST	BALL BEARING (2 REQ.)
55A	55-130	BALL BEARING (4 REQ.)
56	56-130	ROD BRACE (2 REQ.)
56C	56C-130VSX	ROD BRACE ASSEMBLY
56P	56P-117	ROD BRACE PAD (2 REQ.)
62	62-50	CLICK SPRING
62A	62-54S	DRAG COVER LOCK SPRING

Model: 130VSX

KEY PART NO.	NO.	DESCRIPTION
63	63-30T	STAND SCREW (6 REQ.)
63A	63A-50	HANDLE KNOB SCREW (REVERSE THREAD)
63B	63-80VS	HANDLE SHAFT SCREW
67	67-70	PINION RETAINING WASHER
67A	67A-70	PINION RETAINING SCREW
67D	67D-130VS	RETAINING RING
69	69-130	DRAG LOCATING PIN (2 REQ.)
69B	69B-130	RETAINING RING (2 REQ.)
81	81-130	CLICK RATCHET PLATE
91	91-80VS	HANDLE SHAFT
95	95-70	CLICK TONGUE BUSHING
95A	95A-50	CLICK BUSHING LOCK WASHER
95B	95B-70	CLICK LOCKING PLATE
101	101-130VS	CLICK RATCHET SCREW (4 REQ.)
101A	101-130S	DRAG WASHER SCREW (3 REQ.)
110A	110A-130VS	HANDLE SCREW LOCKING RING
110B	110B-130VS	SHIFTER BASE ASSEMBLY
110C	110C-130VS	SHIFT BUTTON RETAINER
112	112-130VS	LEVER KNOB ASSEMBLY
112A	112A-130VS	SLEEVE
112B	112B-130VS-1	LEVER KNOB
112C	112C-30VS	CLICK PLATE
112E	112E-30VS	CLICK PLATE HOUSING
117	117-130	DRIVE PLATE (OUTER)
117A	117A-130	DRIVE PLATE (INNER)
118	118-80S	DRIVE PLATE SCREW (8 REQ.)
119	119-130VS	SHIFT PLATE
124L	124L-130VS	BRIDGE COVER ASSEMBLY
128A	128A-130VS	DRIVE PLATE
128B	128B-130VS	DRIVE PLATE (2 REQ.)
128C	128C-130VS	MAIN GEAR CONNECTING PLATE
133	133-30VS	RETAINING CLIP
134	134-130VS	GEAR STUD
134B	134B-130VS	SHIFTER SLEEVE (2 REQ.)
134D	134D-130VS	SHIFTER BUSHING
141	141-130VS	CAM FOLLOWER
143	143-130VS	ADJUSTING SCREW
152A	152A-80T	ROD CLAMP ACORN NUT (2 REQ.)
154	154-130	SPOOL SHIM (2 REQ.)
155	155-130	TURNBUCKLE (2 REQ.)
156	156-130VS	DRAG COVER
156A	156A-30VS	DRAG COVER LOCK PIN
156B	156B-30VS	DRAG COVER LOCK PLATE
161	161-130VS	LOCATING PIN BUSHING (2 REQ.)
162	162-130	LOCATING PIN SPRING (2 REQ.)
165	165-116	RIGHT HAND SCREW HOOK (4 REQ.)
170	170-30VS	CATCH ASSEMBLY
171	171-15KG	SHIFTER PLUNGER
172B	172B-130S	SHIFTER SPACER
173	173-30VS	SHIFTER CATCH (2 REQ.)
173A	173A-30VS	SHIFTER CATCH HOLDER
173B	173-130VS	RETAINING RING
183	183-130VSX	TUBE FRAME
185	185-24KG	SPIRAL RETAINING RING
185A	185-600	RETAINING RING
264	264-130ST	STAND GASKET
302D	302D-52MMAG	SPRING

