
Penn 115L-LH 9/0 Senator Left Hand



Penn Reel Parts list for: Model: 115L-LH **9/0 Senator**

KEY NO	PART NO.	DESCRIPTION	KEY NO	PART NO.	DESCRIPTION
1	1-115LH	LEFT SIDE PLATE (LEFT HAND)	27	27-115	RIGHT SIDE PLATE
2	2-115-O	SIDE PLATE RING-OUTER	28	28-115-I	RIGHT SIDE INNER
2A	2-115-I	LEFT SIDE RING-INNER	29	29L-115	SPOOL-ALUMINUM
3	3-115LH	BRIDGE W/ SLEEVE (LEFT HAND)	30	30-115	STAND
4	4-115	FIBER WASHER	31	39-12	R.S. STAND SCREW (3 REQ.)
5	5-115LH	MAIN GEAR (LEFT HAND)	32	32-21	R.S. STAND SCREW (3 REQ.)
6	6-115	DRAG WASHER (5 REQ.)	33	33-340	ROD CLAMP
7	7c-115	METAL DRAG WASHER SET	*	*33R-114	RINGED ROD CLAMP (OPTIONAL)
8A	8-115	TENSION SPRING	34	34-45	CLAMP SCREW (2 REQ.)
9	9-114	SPACING SLEEVE	34C	34C-45	ROD CLAMP SCREW W/ NUTS
10	10-114	STAR DRAG WHEEL	35	35-115	CLICK TONGUE
11	11-115	ECCENTRIC JACK	36	36-115	CLICK BUTTON
12	12-114	PINION YOKE	37	37-115	FRAME POST (5 REQ.)
13	13-114LH	PINION (LEFT HAND)	38	39-13	R.S. POST SCREW (5 REQ.)
14	14-116	DOG SPRING	39	39-12	L.S. POST SCREW (5 REQ.)
15	15-115	DOG	40	40-114H	L.S. BEARING
16	16-114	BRIDGE SCREW LOWER (2 REQ.)	54	54-114	HARNESS LUG (4 REQ.)
17	17-114	BRIDGE SCREW UPPER (2 REQ.)	56	56-116	ROD BRACE (ONLY)
18	18-114	CLUTCH SPRING	56C	56C-115	ROD BRACE COMPLETE
19	19-115	ECCENTRIC	98	98-114LH	GEAR SLEEVE (LEFT HAND)
20	20-114	ECCENTRIC SPRING	99	99-115	HOOK SCREW L.H. THREW (2 REQ.)
21	21-114	ECCENTRIC LEVER	136	136-115	PRESSURE PLATE WASHER
22	23-60	ECCCENTRIC SCREW	140	140-115	FELT WASHER
23	23-116	HANDLE SCREW	149	149-45	CLAMP NUT (2 REQ.)
23A	110-60	HANDLE LOCK SCREW	149A	149-200	HEX NUT (2 REQ.)
24	24-115	HANDLE	155	155-115	TURN BUCKLE (2 REQ.)
26	26-116	R.S. BEARING	165	165-115	HOOK SCREW R.H. THREAD (2 REQ.)

** Not Shown*